

MINK Hydrogen

Hydrogen Recirculation Blower
MH 0040 A

Instruction Manual



Table of Contents

1	Safety	3
2	Product Description	4
2.1	Operating Principle	5
2.2	Intended Use	5
2.3	Water Cooling	5
2.4	Sealing Gas System	5
2.5	Water Drainage	6
3	Transport	7
4	Storage.....	8
5	Installation.....	9
5.1	Installation Conditions	9
5.2	Connecting Lines / Pipes	10
5.2.1	Suction Connection	11
5.2.2	Discharge Connection.....	12
5.2.3	Cooling Water Connection	13
5.2.4	Barrier Gas System Connection.....	14
5.2.5	Drainage Connection	14
6	Electrical Connection	15
6.1	Machine delivered with a Variable Speed Drive	15
6.2	Terminal Connection	16
6.2.1	Earth Connection	16
6.3	Signal Connection	17
7	Commissioning	18
8	Maintenance	20
8.1	Maintenance Schedule	21
8.2	Oil Draining	22
8.2.1	Draining Procedure.....	22
8.3	Cleaning from Dust and Dirt.....	23
9	Overhaul	24
9.1	Replacement Pump-Unit	25
9.1.1	Scope of Delivery	25
9.1.2	Removal and Installing the Unit	26
10	Decommissioning	28
10.1	Dismantling and Disposal	28
11	Spare Parts	29
12	CAN Protocol	30
12.1	CAN Matrix.....	30
13	Troubleshooting	35
14	Technical Data	37
15	Oil	38
16	EU Declaration of Conformity	39
17	UK Declaration of Conformity.....	40

1 Safety

Prior to handling the machine, this instruction manual should be read and understood. If anything needs to be clarified, please contact your Busch representative.

Read this manual carefully before use and keep for future reference.

This instruction manual remains valid as long as the customer does not change anything on the product.

The machine is intended for industrial use. It must be handled only by technically trained personnel.

The machine is intended for use under monitored laboratory conditions. It must be handled only by technically trained personnel.

Always wear appropriate personal protective equipment in accordance with the local regulations.

The machine has been designed and manufactured in accordance with the state-of-the-art methods. Nevertheless, residual risks may remain, as described in the following chapters and in accordance with the chapter *Intended Use* [→ 5].

This instruction manual highlights potential hazards where appropriate. Safety notes and warning messages are tagged with one of the keywords DANGER, WARNING, CAUTION, NOTICE and NOTE as follows:



DANGER

... indicates an imminent dangerous situation that will result in death or serious injuries if not prevented.



WARNING

... indicates a potentially dangerous situation that could result in death or serious injuries.



CAUTION

... indicates a potentially dangerous situation that could result in minor injuries.



NOTICE


... indicates a potentially dangerous situation that could result in damage to property.



NOTE

... indicates helpful tips and recommendations, as well as information for efficient and trouble-free operation.

2 Product Description



*Incl. USB-Drive with CAN database

Description			
IN	Inlet connection (connected to fuel cell inlet, 20 Nm)	OUT	Pressure connection (connected to fuel cell outlet, 20 Nm)
OFP/ODP	Oil fill/drain plug	ECP	Machine earth connection (M5, 8 Nm)
CWI	Cooling water inlet (<1 lpm, G1/4", 10 Nm)	CWO	Cooling water outlet (G1/4", 10 Nm)
SG	Sealing gas (G1/8", 8 Nm)	WD	Water drainage (G1/8", 8 Nm)
*CAN	CAN connector (Tyco)	PT	Power terminals (M6, 8 Nm)
DA	Directional arrow	NP	Nameplate

NOTE

Technical term.


In this instruction manual, we consider that the term 'machine' refers to the 'compressor'.

NOTE

Illustrations.

In this instruction manual, the illustrations may differ from the appearance of the machine.

2.1 Operating Principle



The machine works on the claw principle.

2.2 Intended Use



WARNING

In case of foreseeable misuse outside the intended use of the machine.

Risk of injuries!

Risk of damage to the machine!

Risk of damage to the environment!

- Make sure to follow all instructions described in this manual.

The machine is intended for the recirculation of hydrogen gases or gas mixtures of nitrogen/humid hydrogen.

The machine is intended to be used with a water separator upstream of the suction connection. Liquid water permanently flowing through the process chamber will reduce its lifetime in a proportion linked to the amount of that liquid water.

The machine is intended for the compression of air and other dry, non-aggressive, non-toxic, non-ignitable and non-explosive gases.

Conveying of other media leads to an increased thermal and/or mechanical load on the machine and is permissible only after a consultation with Busch.

The machine is intended for the placement in a non-potentially explosive environment.

The machine is suitable for continuous operation.

Permitted environmental conditions, see *Technical Data* [→ 37].

2.3 Water Cooling

Liquid cooling for the electronic components of the control. The electronics cuts off at 110°C. This temperature will be reached according to the overpressure, inlet- and ambient temperatures. The cooling is therefore mandatory in some operating points ranges (see the mapping performed with air at different temperatures).

2.4 Sealing Gas System

The sealing gas is **necessary** to improve the sealing efficiency and to protect the gearbox from water from the system. Connect the sealing gas port to a **dry gas source** (N₂, H₂, other compatible with process gas).


2.5 Water Drainage

Water from the recirculation circuit, which collects on the suction side of the machine, can be drained through the drainage connection.

- Protects the sealing system
- Protect the machine from frozen water at low temperatures

3 Transport

- To find out the weight of the machine, refer to the chapter *Technical Data* [→ 37] or the nameplate (NP).



- Check the machine for transport damage.
- If the machine is secured to a base plate:
- Remove the machine from the base plate.

4 Storage

- Seal all apertures with adhesive tape or reuse provided caps, if not connected to a system.

If the machine is to be stored for more than 2 months:

- Make sure that the inside of the process chamber will be kept dry and dust free at ambient temperature.
- Make sure the machine is stored in a horizontal position..
- Before restarting the machine after a long period of machine shutdown, it is recommended to maintain as described in chapter *Oil Draining* [→ 22].
- After storage for more than 2 years, check the machine for oil leaks - visual inspection.

5 Installation

5.1 Installation Conditions



WARNING

Hydrogen leaks.

Risk of severe injury!

Risk of explosion!

- Perform a hydrogen leak test of the entire system in order to fulfill a maximum leak rate of 10 Ncm³/h.
- Please refer to the Commission Regulation (EU) No 406/2010 and the Regulation (EU) No 79/2009.
- Make sure the machine is vented enough or monitored by a hydrogen sensor.
- Make sure that no excess pressure of more than 3.0 bar(a) reaches the machine inlet.




NOTICE

Use of the machine outside of the permitted installation conditions.

Risk of premature failure!

Loss of efficiency!

- Make sure that the installation conditions are fully respected.



Description

1	Installation on top or bottom M6 (8 Nm)	2	Horizontal installation with 2 possible configuration
---	---	---	---

- Make sure that the environment of the machine is not potentially explosive.
- Make sure that the ambient conditions comply with the *Technical Data* [→ 37].
- Make sure that the environmental conditions comply with the protection class of the motor and the electrical elements.
- Make sure that the installation space or location is protected from weather and lightning.
- We strongly recommend to install the product at the top level of the fluid circuit to avoid the stagnation of condensates inside the compression stage.
- Make sure that enough space remains for maintenance work.
- Make sure that the machine is placed or mounted horizontally on a flat surface.
- Make sure that all provided covers, guards, hoods, etc. are mounted.



WARNING

Vibration level.

Risk of premature failure!

- Make sure the product is protected from external shocks. Regarding vibration level, please contact your Busch representative to discuss the corresponding levels.

5.2 Connecting Lines / Pipes



WARNING

Unprotected connection.

Risk of severe injury!

- Do not put hand or fingers in the connection.
 - Remove all protective covers before installation.
 - Make sure that the connection lines cause no stress on the connections of the machine. Therefore, we recommend installing flexible lines on the suction and discharge connections.
 - Make sure that the diameter of the connection lines over the entire length is at least as large as the connections of the machine.
 - Make sure that no dust or other particles can enter into the machine.
- In case of long connection lines, it is recommended to use larger diameters in order to avoid a loss of efficiency. In case, contact your Busch representative.
- Make sure that the connections are “face sealed” and not “thread sealed” to ensure tightness.

5.2.1 Suction Connection



WARNING

Unprotected connection.

Risk of severe injury!

- Do not put hand or fingers in the connection.



NOTICE

Inlet gas particle size.

Risk of damage to the machine!

- Make sure that the inlet gas complies with ISO 12103-1, A.2 fine test dust.



NOTICE

Ingress of foreign objects or liquids.

Risk of damage to the machine!

If the inlet gas contains dust or other foreign solid particles:

- Install a suitable filter (5 micron or less) upstream from the machine.
- Make sure that the filter is suitable to the pumping speed of the machine, see *Technical Data* [→ 37].
- Make sure that the filter material is suitable for hydrogen applications.

Connection size(s):

- G1"

Depending on the specific configuration ordered, other connection dimensions may apply.

- Make sure that the gas is drawn without obstruction.
- Provide a water separator upstream of the suction connection. Liquid water permanently flowing through the process chamber will reduce its lifetime in a proportion linked to the amount of that liquid water.
- Make sure that the water separator is suitable to the pumping speed of the machine, see *Technical Data* [→ 37].
- Make sure that the connection lines cause no stress on the connections of the machine. Therefore, we recommend installing flexible lines on the suction and discharge connections.

5.2.2 Discharge Connection



WARNING

Unprotected connection.

Risk of severe injury!

- Do not put hand or fingers in the connection.



NOTICE

Discharge gas flow obstructed.

Risk of damage to the machine!

- Make sure that the discharged gas will flow without obstruction. Do not shut off or throttle the discharge line.


Connection size(s):

- G1"

Depending on the specific configuration ordered, other connection dimensions may apply.

- Make sure that the connection lines cause no stress on the connections of the machine. Therefore, we recommend installing flexible lines on the suction and discharge connections.

5.2.3 Cooling Water Connection



Description			
CWO	Cooling water outlet G1/4" (10 Nm)	CWI	Cooling water inlet G1/4" (10 Nm)

- Connect the cooling water connections (CWI / CWO) to the water supply.

Connection size:

- G ¼" (CWC)
- Materials in contact with the cooling water: Aluminum (EN-AW 5083)
- Make sure that the cooling water complies with the following requirements:

Supply capacity	l/min	min. 0.5
Water pressure	bar	1 ... 4
Supply temperature	°C	+5 ... +80
Required pressure differential across supply and return	bar	0.05

- To reduce the maintenance effort and ensure a long product lifetime, we recommend the following cooling water quality:

Hardness	mg/l (ppm)	< 90
Properties	Clean & clear	
PH value		
Particle size	µm	< 200
Chloride	mg/l	< 100
Electrical conductivity	µS/cm	≤ 100
Free chloride	mg/l	< 0.3
Materials in contact with the cooling water		

**NOTE**

Water hardness unit conversion.

1 mg/l (ppm) = 0.056 °dh (german degree) = 0.07 °e (english degree) = 0.1 °fH (french degree)

5.2.4 Barrier Gas System Connection

- Connect the barrier gas connection (BGC) to the gas supply.

Connection size:

– G1/8"

- Make sure that the gas complies with the following requirements:

Gas type	Dry nitrogen, hydrogen, other compatible with process gas	
Gas temperature	°C	0 ... 95
Maximum gas pressure	bar (g)	System pressure at IN (tolerance 0 ... +0.4 bar(g))
Recommended pressure setting at the pressure safety valve	bar (g)	2.7
Filtration	µm	5
Recommended flow rate	SLM (standard liter per minute)	-

5.2.5 Drainage Connection

**WARNING**

Hydrogen leaks.

Risk of severe injury!

Risk of explosion!

- Perform a hydrogen leak test of the entire system in order to fulfill a maximum leak rate of 10 Ncm³/h.
- Please refer to the Commission Regulation (EU) No 406/2010 and the Regulation (EU) No 79/2009.
- Make sure the machine is vented enough or monitored by a hydrogen sensor.
- Make sure that no excess pressure of more than 3.0 bar(a) reaches the machine inlet.

Connection size:

– G1/8"

- Use the option of draining the machine if more than 0,2l/h water flow through the compressor chamber. Maximum water capacity of the machine = 2.5 l/h.
- Consider that the drainage system is pressurized with the pressure of the recirculation circuit.
- Connect the Drainage to the inlet connection (IN) if there is no drainage circuit.
- In case of a leak (hydrogen), escape.

6 Electrical Connection



DANGER

Live wires.

Risk of electrical shock.

- Electrical installation work must only be executed by qualified personnel.



NOTICE


Electromagnetic compatibility.

- Make sure that the motor of the machine will not be affected by electric or electromagnetic disturbance from the mains, if necessary, seek advice from Busch.
- Make sure that the EMC of the machine is compliant with the requirements of your supply network system, if necessary, provide further interference suppression (EMC of the machine, see *EU Declaration of Conformity* [→ 39] or *UK Declaration of Conformity* [→ 40]).
- Make sure that the motor of the machine will not be affected by electric or electromagnetic disturbance from the mains, if necessary seek advice from Busch.
- Electrically connect the machine
- Due to current level, recommended cable diameter min. 16 mm².

6.1 Machine delivered with a Variable Speed Drive

- If the variable speed drive is not equipped with a lockable disconnect switch, provide it on the power line so that the machine is completely secured during maintenance tasks.
- Provide an overload protection according to EN 60204-1.
- Connect the protective earth conductor.

6.2 Terminal Connection




Description

1	Battery power connection Terminal supply "+" Bolt M6x12 (8 Nm)	2	Battery power connection Terminal supply "-" Bolt M6x12 (8 Nm)
---	--	---	--

- A visual Poke yoke is defining the "+" (red) and "-" (black)
- Coating bolts: Zn/Ni
- Ensure a good contact with his cable lungs for the electrical cone
- In case of harsh environment foreseen the protection of this area against corrosive mist

6.2.1 Earth Connection




Description

ECP	Equipotential connection M6 (8 Nm)		
-----	------------------------------------	--	--

6.3 Signal Connection

The motor has a 16 pins signal connector.


TE Socket 1488345 for plug TE GET.64 / 5-1419168-8



According to TE specification unused pins shall be closed in order to ensure IP6K9K protection.


PIN Number	Assignment	Comment
1	CAN_L	CAN Low
2	D_IO_1	Not used
3	CAN_H	CAN High
4	DGND	Not used
5	Wake up	Not used
6	5V_IO	5V supply for Killswitch
7	Killswitch	Enable Power stage
8	5V_1	Not used
9	AN_1	Not used
10	A_GND_1	Not used
11	5V_2	Not used
12	AN_2	Not used
13	A_GND_2	Not used
14	5V_3	Not used
15	AN_3	Not used
16	A_GND_3	Not used

Signal cable



Description			
1	Plug TE GET.64 / 5-1419168-8	2	SUB-D 9 male (for CAN communication)
3	Killswitch (yellow cable)	4	5V_IO (red cable)

1. Connect the signal cable
2. Use M6 nuts to connect the two cables (V- and V+)
3. "Killswitch" (yellow) cable to the "5V_IO" (red) cable
If required, install an emergency stop switch between the red- and yellow connector.
4. Connect the PCAN USB (not in scope) interface to your computer / system
5. Power on the machine with an external power supply or battery



7 Commissioning



NOTICE

Lubricating a dry running machine (compression chamber).

Risk of damage to the machine!

- Do not lubricate the compression chamber of the machine with oil or grease.



NOTICE

Ambient temperature below 0°C.

Risk of damage to the machine!

- Use a cooling liquid with an antifreeze mixture (ratio 1:1).



CAUTION

During operation the surface of the machine may reach temperatures of more than 70°C.

Risk of burns!

- Avoid contact with the machine during and directly after operation.



CAUTION



Noise of running machine.

Risk of damage to hearing!

If people are present in the vicinity of a machine that is not insulated from noise for extended periods of time:

- Make sure to wear hearing protection.
- Make sure that the *Installation Conditions* [→ 9] are met.
 - Turn on the water supply.
- Start the machine.
- Make sure that the maximum permissible number of starts does not exceed 12 starts per hour. Those starts should be spread within the hour.
- Make sure that the operating conditions comply with the *Technical Data* [→ 37].

As soon as the machine is operated under normal operating conditions:

- Measure the motor current and record it as reference for future maintenance and trouble-shooting work.



NOTICE

Oil losses through the barrier gas connection

Risk of damage to the machine!

Pressurize and vent the barrier gas system only while the machine is operating, by following this sequence:

- **Switch on** the machine.
- Set the rotation speed between 4000 rpm and 6000 rpm, then pressurize the barrier gas system.
- **Switch off** the machine.
- Set the rotation speed between 4000 rpm and 6000 rpm, then vent the barrier gas system to atmospheric pressure and finally stop the machine.

CAN Communication Matrix on the USB stick:

- .dbc file
- .pdf file

CAN Connector and Voltage data

Nominal voltage	24 V DC
Voltage range	15 ... 35 V DC
Ambient temperature range	-30 ... 95°C
Maximum electronic temperature (PCB)	110°C
Rotation speed range	1200 ... 6000 rpm
Maximum power consumption	50 A
Baud rate CAN	500 kbits/s
Overvoltage (switch off / error)	>35 V DC
Undervoltage (switch off / error)	<15 V DC

8 Maintenance



DANGER

Live wires.

Risk of electrical shock.

- Electrical installation work must only be executed by qualified personnel.



WARNING



The machine is contaminated with hazardous material.

Risk of poisoning!

Risk of infection!

If the machine is contaminated with hazardous material:

- Wear appropriate personal protective equipment.



CAUTION

Hot surface.

Risk of burns!

- Before doing anything that requires touching the machine, let it cool down first.



CAUTION

Failing to properly maintain the machine.

Risk of injuries!

Risk of premature failure and loss of efficiency!

- Maintenance work must only be executed by qualified personnel.
- Respect the maintenance intervals or ask your Busch representative for service.

- Make sure that the system has no high hydrogen concentration.
- Shut down the machine and lock against inadvertent start up.
- Provide a lockable disconnecting switch in the power line to ensure that the machine is completely secured against inadvertent start up during the whole maintenance procedure.
- Disconnect the power supply.

If the machine is equipped with a barrier gas system:

- Close the barrier gas supply.
- Turn off the water supply.
- Vent the connected lines to atmospheric pressure.

If necessary:

- Disconnect all connections.
- Separate special waste from the machine.
- Dispose of special waste in compliance with applicable regulations.
- Dispose of the machine as scrap metal.

8.1 Maintenance Schedule

The maintenance intervals depend very much on the individual operating conditions. The intervals given below are desired to be considered as starting values which should be shortened or extended as appropriate. Particularly harsh applications such as high liquid water content in the process gas, other contamination or ingress of process material, can make it necessary to shorten the maintenance intervals significantly.

The following maintenance schedule has been defined as information according to internal tests performed at Busch.



NOTE

Final maintenance schedule.

The final maintenance schedule must be committed between customers and Busch, based on field test results and analysis.

Interval	Maintenance work
Every 4000 to 6000 hours or after 6 years	<ul style="list-style-type: none">• Replace oil, see <i>Oil Draining</i> [→ 22].

8.2

Oil Draining

8.2.1

Draining Procedure

Draining the oil

!

NOTICE

Use of an inappropriate oil.

Risk of premature failure!

Loss of efficiency!

- Only use an oil type which has previously been approved and recommended by Busch.


i

NOTE

Oil draining.


Recommendation.

- There is no ideal angle to put the gear for oil draining. We would recommend to move the gear-box several times from standard “vertical position” to a 90° position. The remaining oil must be the lowest possible.



Description			
OFP	Oil fill plug	ODP	Oil drain plug
1	Clean or if necessary replace the plug	2	Fill till reaching close to the lower edge of the filling hole (approx. 90 ml)
3	Tighten the plug with 7 Nm torque		

8.3 Cleaning from Dust and Dirt



Description			
1	Clean the surface of the machine and power unit		

9

Overhaul

**WARNING**

The machine is contaminated with hazardous material.

Risk of poisoning!

Risk of infection!

If the machine is contaminated with hazardous material:

- Wear appropriate personal protective equipment.

**NOTICE**

Improper assembly.

Risk of premature failure!

Loss of efficiency!

- Any dismantling of the machine that goes beyond anything that is described in this manual should be done by Busch authorized technicians.

In case of the machine having conveyed gas that was contaminated with foreign materials which are dangerous to health:

- Decontaminate the machine as much as possible and state the contamination status in a 'Declaration of Contamination'.

Busch will only accept machine accompanied by a signed, fully completed and legally binding "declaration of contamination", downloadable from the following link:
buschvacuum.com/declaration-of-contamination.

9.1 Replacement Pump-Unit



DANGER

Strong magnetic field

For persons with pacemakers there is a danger to life.



WARNING

Strong magnetic field.

Risk of injury due to uncontrolled mutual attraction of magnetic or magnetizable parts!

- Take into account the magnetic forces occurring during all operations, especially within a radius of 0.5 m around the magnetic coupling.




CAUTION

Restriction of the separator vent.

Magnetic data carriers (floppy disks, credit cards, etc.) can be damaged or erased by magnetic fields.

- Keep a minimum distance of 1 m from the magnetic field.


9.1.1 Scope of Delivery




Description

1	Nameplate	2	O-ring
3	4x screws M6 (installation drive-unit)	4	3x screws M6 (installation base plate)
5	Pump-unit		


9.1.2 Removal and Installing the Unit



Description			
1	Loosen the screws and remove the base plate	2	Loosen the screws and remove the motor unit and the o-ring




Description			
3	Remove the old nameplate from the drive-unit	4	Dispose the defective pump-unit and used o-ring, screws and nameplate in compliance with applicable regulations of your country



Description

5	Clean the contact surfaces from debris and liquids with a cloth	6	First lubricate the o-ring with grease, then insert the o-ring into the groove
---	---	---	--



Description

7	Install the drive-unit to the new pump-unit with the 4x screws M6 (8 Nm)	8	Install the base plate to the pump-unit with the 3x screws M6 (8 Nm)
9	Reapply the new nameplate on the drive-unit		

10 Decommissioning



DANGER

Live wires.

Risk of electrical shock.

- Electrical installation work must only be executed by qualified personnel.
-



CAUTION

Hot surface.

Risk of burns!

- Before doing anything that requires touching the machine, let it cool down first.
-

- Shut down the machine and lock against inadvertent start up.
- Disconnect the power supply.
- Turn off the water supply.

If the machine is equipped with a barrier gas system:

- Close the barrier gas supply.
- Vent the connected lines to atmospheric pressure.
- Disconnect all connections.

If the machine is to be stored:

- See Storage.

10.1 Dismantling and Disposal

- Drain and collect the oil.
- Make sure that no oil drips onto the floor.
- Separate special waste from the machine.
- Dispose of special waste in compliance with applicable regulations.
- Dispose of the machine as scrap metal.

11 Spare Parts



NOTICE

Use of non-Busch genuine spare parts.

Risk of premature failure!

Loss of efficiency!

- The exclusive use of Busch genuine spare parts and consumables is recommended for the correct functioning of the machine and to validate the warranty.

Spare part	Description	Part no.
Oil fill/drain plug (OFP/ODP)		0415 153 401
Overhaul kit	Replacement stage, seal, screws, nameplate	2000 096 045

If other parts are required:

- Contact your Busch representative.

12 CAN Protocol

12.1 CAN Matrix

Rev B 08.05.2023

CAN Communication Matrix									
Legend:		Fix configuration: High-speed CAN bus (ISO 11898) Customer: ECU MH0040: MCU							
(Hex)	Hexadecimal Format in MSB	(rpm)	Unit for speed						
(Dec)	Decimal Format	(ms)	Unit for milliseconds						
Message Name	Identifier (29bit)(Hex) x=Offset see color table	Cycle time (ms)	Source	Receiver	Signal Name	Start on Bit	Bit Length	Data (Hex)	Explanation
									Protocol values (range) on CAN
									What the motor physically run
									Comments including - limitations - description of base functionality - description of the signal meaning
Set value from Customer ECU to Pump motor MCU									
Motor/Control	18FF333x	10	ECU	MCU	SpeedRequest	0 16		707F AC5F F600	0 rpm - 6000rpm Spin out
									0.5 -32127
									44127
									CAN Min Value (Dec)
									CAN Max Value (Dec)
									Speed (rpm)
									What the motor physically run
Motor/Control	18FF333x	10	ECU	MCU	TorqueRequest	16	16FFFF	Nor Active	Example for stop
									0 707F
									Minimal speed 1000 rpm
									854F
									2000 8D1F
									Speed 2000 rpm
									3000 94FF
Motor/Control	18FF333x	10	ECU	MCU	Position Request	32	32FFFFFFF	Not Active	Speed 3000 rpm
									4000 9CBF
									Speed 4000 rpm
									5000 A48F
									Speed 5000 rpm
									6000 ACSF
									Speed 6000 rpm
Motor/Control	18FF333x	10	ECU	MCU					must set FFFF (use only speed setting)
									must set FFFFFFFF (use only speed setting)

Protocol values (range) on CAN															What the motor physically run	Comments including limitations - description of base functionality - description of the signal meaning
CAN Min Value (Dec)												CAN Max Value (Dec)		Speed (rpm)	CAN Value (Hex)	
Message Name	Identifier (29bit)(Hex) x=Offset	Cycle time (ms)	Source	Receiver	Signal Name	Start on Bit	Bit Length	Data (Hex)	Explanation	Resolution	Offset (Dec)					
One time configuration from customer ECU to Pump motor MCU																
MotorConfig	18FF343x	Async	ECU	MCU	Max DC current	0	8	0..FA FF	Values	1	0	0	250	Unit: A Valid input 0..250A. Internally limited to 0..120A	Reserved = not used	
									Not Active				If not Active, default value of parameter Ibr. CircIbrMax is used (Strong recommended!)			
MotorConfig	18FF343x	Async	ECU	MCU	Min DC current	8	8	0..FA FF	Values	1	0	0	250	Unit: A Valid input 0..250A. Internally limited to 0..120A	Reserved = not used	
									Not Active				If not Active, default value of parameter Ibr. CircIbrMin is used (Strong recommended!)			
MotorConfig	18FF343x	Async	ECU	MCU	Max Iq current	16	8	0..FA FF	Values	1	0	0	250	Unit: A Valid input 0..250A. Internally limited to 0..120A	Reserved = not used	
									Not Active				If not Active, default value of parameter IqMax is used (Strong recommended!)			
MotorConfig	18FF343x	Async	ECU	MCU	Min Iq current	24	8	0..FA FF	Values	1	0	0	250	Unit: A Valid input 0..250A. Internally limited to 0..120A	Reserved = not used	
									Not Active				If not Active, default value of parameter IqMin is used (Strong recommended!)			
MotorConfig	18FF343x	Async	ECU	MCU	Max speed	32	16	0..2EED FFFE FFFF	Values	0.5	0	0	12000	Unit: rpm/2 Valid input 0..12 000. For Motor possible 0..6000rpm = 0..12 000 (DEC) = 0..2EED (Hex)	Reserved = not used	
									Not Active				If not Active, default value of parameter customer.Nmax is used			
Actual Messages from Pump motor MCU to Customer ECU																
Motor Feedback1	18FF312x	10	MCU	ECU	Actual speed	0	16	7D7F...AC5F 2EEL...FFFE FE00 FFFE	Values	0.5	32127	32127	44127	6000	AC5F	Unit: rpm/2 Actual speed of the motor output 0..12 000. 0..6000rpm = 0..12 000 (DEC) = 0..2EED (Hex)
									Reserved				Reserved = not used (except Error)			
Motor Feedback1	18FF312x	10	MCU	ECU	Target speed	16	16	0..2EED FFFE FFFE	Not Available							Error will be sent if the MCU cannot provide the motor speed due to failure of speed sensing system.
									Not Available				Not Available is sent if MCU is not available, example: running start-up sequence.			
Motor Feedback1	18FF312x	10	MCU	ECU	Actual Torque	32	16	0..DDF FFFE FFFE	Values	0.5	32127	32127	44127	6000	2EED	Target speed 0-6000 rpm
									Reserved				Reserved = not used			
Motor Feedback1	18FF312x	10	MCU	ECU	Actual Torque	32	16	0..DDF FFFE FFFE	Not Available							Not Available is sent if the motor is not in speed control mode.
									Not Available				Unit: A. Actual torque building phase current (Iq) between -50A ... +50A			
Motor Feedback1	18FF312x	10	MCU	ECU	Actual Current	48	8	0..FD FF	Values	0.015	32127	32127	0	65536		Torque in Nm is calculated by 0.56: Example 20A * 0.56Nm/A = 11.2Nm
									Error				Error			
Motor Feedback1	18FF312x	10	MCU	ECU	Actual Torque	32	16	0..DDF FFFE FFFE	Not Available							Not Available is sent if Enable Pin is low.
									Not Available				Unit: A. Estimation of total current consumption of MCU.			
Motor Feedback1	18FF312x	10	MCU	ECU	Actual Current	48	8	0..FD FF	Values	2	-126	0	250			Total Current over 130A additional Failure Cut Off is set.
									Error				Not Available is set on start-up.			
Motor Feedback1	18FF312x	10	MCU	ECU	Message Counter	56	4	FF	Not Available							Cyclic Message counter (0-15) that increments with each message transmission.
									Not Available				The 4 bit checksum is the sum of the high nibble and the low nibble of the sum of the identifier, the first 7 data bytes and the 4 bit message counter. It is calculated as follows:			
Motor Feedback1	18FF312x	10	MCU	ECU	Message Chelsum	60	4		Checksum = (Byte1 * Byte2 * Byte3 * Byte4 * Byte5 * Byte6 * Byte7 * message counter) XOR * message ID low byte + message ID mid low byte + message ID mid high byte + message ID high byte)							
									Not Available							

Motor Feedback2 is not needed for the MH040. The results arriving from identifier 18FF362x can be ignored.

Status Message Part 1									
Message Name	Identifier (29bit)(Hex) *Offset	Cycle time (ms)	Source	Receiver	Signal Name	Start on Bit	Bit Length	Data (Hex)	Explanation
									Resolution
									Offset (Dec)
								CAN Min Value (Dec)	CAN Max Value (Dec)
								Speed (rpm)	CAN Value (Hex)
									Comments including limitations description of base functionality description of the signal meaning
Status from Pump motor MCU to Customer ECU									
Motor Status	18FF342x	100/MSU	ECU		Operational State	0	4	00,0B,0C,0D,0E,0F	Ready/Normal Motor degraded Reserved Disabled Failure Not Ready
Motor Status	18FF342x	100/MSU	ECU		Temp Limit Warning	4	2	01,02,03	Temperature ok Limits Exceeded Error Not Available
Motor Status	18FF342x	100/MSU	ECU		Analog Ctrl Cut Off	8	2	01,02,03	Signal ok Motor Cut Off Error Not Available
Motor Status	18FF342x	100/MSU	ECU		Under Voltage Cut Off filtered by 50Hz	10	2	01,02,03	Voltage ok Motor Cut Off Error Not Available
Motor Status	18FF342x	100/MSU	ECU		Over Voltage Cut Off filtered by 50Hz	12	2	01,02,03	Voltage ok Motor Cut Off Error Not Available
Motor Status	18FF342x	100/MSU	ECU		Over Temp Cut Off	14	2	01,02,03	Temperature ok Motor Cut Off Error Not Available
Motor Status	18FF342x	100/MSU	ECU		Motor Blocked	16	2	01,02,03	Motor ok Motor blocked Reserved Not Available
Motor Status	18FF342x	100/MSU	ECU		Internal Failure	18	2	01,02,03	Normal operation Internal failure Reserved Not Available
Motor Status	18FF342x	100/MSU	ECU		Actual Control Mode	20	4	04,0D,0E,0F	Not selected Speed control Torque control Position control Reserved Error Not Available

Status Message Part 2

Status Message Part 2																
Message Name	Identifier (29bit)(Hex) x=Offset see color table	Cycle time [ms]	Source	Receiver	Signal Name	Start on Bit	Bit Length	Data (Hex)	Explanation	Resolution	Offset (Dec)	Protocol values (range) on CAN	What the motor physically run			
												CAN Min Value (Dec)	CAN Max Value (Dec)	Speed [rpm] (on Motor)	CAN Value (Hex) (on Motor)	Comments including - limitations - description of base functionality - description of the signal meaning
Motor Status	18FF342x	100	MCU	ECU	Supply Voltage	26	8	00..FD FE FF	Voltage value Error Not Available	0.5	0	0	256	256	Not used	Measured supply Voltage [V/2] Not used
Motor Status	18FF342x	100	MCU	ECU	Temp/Power Stage	34	8	00..FA FB..FD FE	Temperature value Reserved Error	1	-40	0	256	256	Not Available during start-up Measured temperature on electronics (40°C..+210°C) Not used	
Motor Status	18FF342x	100	MCU	ECU	Kill switch open	42	2	01 02	Kill switch open Reserved Not Available	1	0	0	4	4	Error on temperature sensor Kill switch open: Motor enable = low Reserved Not Available	
Motor Status	18FF342x	100	MCU	ECU	Casing temperature	44	8	00..FA FB..FD FE FF	Temperature value Reserved Error Not Available	1	-40	0	256	256	Measured temperature on housing (40°C..+210°C) Not used	
Motor Status	18FF342x	100	MCU	ECU	Message Counter	56	4	FF	Not Available	1	0	0	16	16	Error on temperature sensor Not Available during start-up Cyclic Message counter (0-15) that increments with each message transmission.	
Motor Status	18FF342x	100	MCU	ECU	Message Checksum	60	4			1	0	0	16	16	The 4 bit checksum is the sum of the high nibble and the low nibble of the sum of the identifier, the first 7 data bytes and the 4 bit message counter. It is calculated as follows: Checksum = (Byte1 + Byte2 + Byte3 + Byte4 + Byte5 + Byte6 + Byte7 + message counter&0DF + message ID low byte + message ID mid low byte + message ID mid high byte + message ID high byte)	
MCU Identity																
Unit Identity	18FF352x	1000	MCU	ECU	Software Version	0	8	00..FD FE FF	Software Version Error Not Available	1	0	0	256	256	Not used	Software Version Not used
Unit Identity	18FF352x	1000	MCU	ECU	Hardware Version	8	8	00..FD FE	Hardware Version Error Not Available	1	0	0	256	256	Not used	Hardware Version: Hex 0B = 11 -> 1.1; 14 -> 2.0 / make Hex to Dec and div by 10 Not used
Unit Identity	18FF352x	1000	MCU	ECU	Manufacturing Date	16	32	0000..FDFFFF FEFFFF FF	Date Error Not Available	1	0	0	4211081215	4211081215	Not used	Format:YYMMDD as Hex value. Example: 2013.04.11 is Hex 20130411 Not used
Unit Identity	18FF352x	1000	MCU	ECU	Serial Number	48	16	FE00..FDFF	Serial Number Error Not Available	1	0	0	64255	64255	Not used	Format:min as hexadecimal value. Examples: s/n 12 is Hex 0012. Max value is 9999, counting per day. Not used

Instruction Manual MINK MH 0040 A_EN_en

13 Troubleshooting



DANGER

Live wires.

Risk of electrical shock.

- Electrical installation work must only be executed by qualified personnel.



CAUTION

Hot surface.

Risk of burns!

- Before doing anything that requires touching the machine, let it cool down first.

Problem	Possible Cause	Remedy
The machine does not start.	The motor is not supplied with the correct voltage.	<ul style="list-style-type: none"> • Check the power supply.
	The motor is defective.	<ul style="list-style-type: none"> • Replace the motor.
	The coupling (CPL) is defective.	<ul style="list-style-type: none"> • Replace the coupling (CPL).
	The rotors are defective.	<ul style="list-style-type: none"> • Replace the pump-unit, see <i>Replacement Pump-Unit</i> [→ 25].
The machine does not start / rotor clogged at ambient temperatures below 0°C.	<p>At temperatures (ambient; electronics; etc.) below 0 °C, the error ROTOR BLOCKED can occur.</p> <p>There is a possibility that the rotor is blocked by frozen water.</p>	<p>Error ROTOR BLOCKED is only removeable by a power-reset.</p> <ul style="list-style-type: none"> • cut off the power supply. (optional: start a heating element to melt the ice) • wait 5 min. • restart the machine and send the starting signal. • if the error still occurs, repeat the steps.
The machine does not work, while the motor is running:	The machine is equipped with a magnetic coupling: The magnetic coupling can't catch the motor on its own.	<ul style="list-style-type: none"> • Stop the motor, wait until the motor stops turning and start again.
The machine does not reach the usual pressure on the discharge connection.	The inlet screen (IS) is partially clogged.	<ul style="list-style-type: none"> • Clean the inlet screen (IS).
	The inlet filter cartridge (optional) is partially clogged.	<ul style="list-style-type: none"> • Replace the inlet filter cartridge.
	The pressure system or pressure line is not leak-tight.	<ul style="list-style-type: none"> • Check the hose or pipe connection for leakage.
	The pressure relief valve/ regulating system (SV) is misadjusted or defective.	<ul style="list-style-type: none"> • Adjust, repair or replace, respectively.
	Internal parts are worn or damaged.	<ul style="list-style-type: none"> • Repair the machine (contact Busch).
	Partial clogging in the discharge or pressure line.	<ul style="list-style-type: none"> • Remove the clogging.

Problem	Possible Cause	Remedy
The machine runs very noisily.	Worn coupling (CPL).	<ul style="list-style-type: none"> • Replace the coupling (CPL).
	Oil level too low.	<ul style="list-style-type: none"> • Top up oil.
	Defective bearings.	<ul style="list-style-type: none"> • Repair the machine (contact Busch).
The machine runs too hot.	Insufficient cooling.	<ul style="list-style-type: none"> • Remove dust and dirt from the machine .
	The cooling fan's rotation direction is incorrect.	<ul style="list-style-type: none"> • Check the rotation direction of the cooling fan, see Machine delivered with a Variable Speed Drive.
	Ambient temperature too high.	<ul style="list-style-type: none"> • Observe the permitted ambient temperature, see <i>Technical Data</i> [→ 37].
	Temperature of the process gases at the inlet too high.	<ul style="list-style-type: none"> • Observe the permitted gas inlet temperature, see <i>Technical Data</i> [→ 37].
	Oil level too low.	<ul style="list-style-type: none"> • Top up oil.

For resolution of problems not listed in the troubleshooting table, please contact your Busch representative.

14 Technical Data

MINK MH 0040 A		
Nominal pumping speed max.	m ³ /h	40
Differential pressure	bar(g)	max. 0.5
Admissible inlet pressure	bar(a)	Atmospheric pressure – max. 3.0
Nominal motor rating	kW	1.0
Nominal motor voltage	VDC	24
Power consumption max.	A	50
Permitted motor speed range	min ⁻¹	1200 – 6000
Sound pressure level (EN ISO 2151) at 6000 min ⁻¹ ; inlet (IN) and outlet (OUT) connected to a system	dB(A)	67
KpA	dB	3
Inlet gas temperature range	°C	-30 ... +95
Ambient temperature range	°C	-30 ... +95
Leakage rate (EU 79/2009 & 406/2010)	Ncm ³ /h	< 10
Ambient pressure		Atmospheric pressure
Oil capacity	l	0.09
Protection class		IP 67
Dimensions (L x W x H)	mm	293 x 183 x 150
Weight approx.	kg	11

High frequency transient phases (with up and down pressure levels) need to be discussed and validated between customers and Busch on applications themselves.

15 Oil

VPA 032	
ISO-VG	32
Part number 0.1 L packaging	0831 253 789
Part number 0.5 L packaging	0831 253 732
Part number 1 L packaging	0831 237 294

Oil suitability

Oil VPA 032:

- Suitable for fuel cells applications.
- Suitable for harsh thermal applications.
- Advanced anti-corrosion properties for applications with:
 - Potential ingress of hydrogens / water
 - Oxygen content of more than 21%
 - Corrosive chemicals

16 EU Declaration of Conformity

This Declaration of Conformity and the CE-markings affixed to the nameplate are valid for the machine within the Busch scope of delivery. This Declaration of Conformity is issued under the sole responsibility of the manufacturer.

When this machine is integrated into a superordinate machinery the manufacturer of the superordinate machinery (this can be the operating company, too) must conduct the conformity assessment process for the superordinate machine or plant, issue the Declaration of Conformity for it and affix the CE-marking.

The manufacturer

Busch Produktions GmbH
Schauinslandstr. 1
DE-79689 Maulburg

declares that the machine: MINK MH 0040 A

fulfill(s) all the relevant provisions from EU directives:

- 'Machinery' 2006/42/EC
- 'Electromagnetic Compatibility' (EMC) 2014/30/EU
- 'RoHS' 2011/65/EU Restriction of the use of certain hazardous substances in electrical and electronic equipment (incl. all related applicable amendments)

and comply(-ies) with the following harmonized standards that have been used to fulfill those provisions:

Standards	Title of the Standard
EN ISO 12100 : 2010	Safety of machinery - Basic concepts, general principles of design
EN ISO 13857 : 2019	Safety of machinery - Safety distances to prevent hazard zones being reached by the upper and lower limbs
EN 1012-1 : 2010 EN 1012-3 : 2013	Compressors - Safety requirements - Part 1 and Part 3
EN ISO 2151 : 2008	Acoustics - Noise test code for compressors and vacuum pumps - Engineering method (grade 2)
EN 60204-1 : 2018	Safety of machinery - Electrical equipment of machines - Part 1: General requirements
EN IEC 61000-6-2 : 2019	Electromagnetic compatibility (EMC) - Generic standards. Immunity for industrial environments
EN IEC 61000-6-4 : 2019	Electromagnetic compatibility (EMC) - Generic standards. Emission standard for industrial environments

Legal person authorized to compile the technical file and authorized representative in the EU (if the manufacturer is not located in the EU):

Busch Dienste GmbH
Schauinslandstr. 1
DE-79689 Maulburg

Maulburg, 02.01.2024



Dr. Martin Gutmann
General Manager
Busch Produktions GmbH

17 UK Declaration of Conformity

This Declaration of Conformity and the UKCA-markings affixed to the nameplate are valid for the machine within the Busch scope of delivery. This Declaration of Conformity is issued under the sole responsibility of the manufacturer.

When this machine is integrated into a superordinate machinery the manufacturer of the superordinate machinery (this can be the operating company, too) must conduct the conformity assessment process for the superordinate machine or plant, issue the Declaration of Conformity for it and affix the UKCA-marking.

The manufacturer

Busch Produktions GmbH
Schauinslandstr. 1
DE-79689 Maulburg

declares that the machine: MINK MH 0040 A

fulfill(s) all the relevant provisions from UK legislations:

- Supply of Machinery (Safety) Regulations 2008
- Electromagnetic Compatibility Regulations 2016
- Restriction of the use of certain hazardous substances in Electrical and Electronic Equipment Regulations 2012

and comply(-ies) with the following designated standards that have been used to fulfill those provisions:

Standards	Title of the Standard
EN ISO 12100 : 2010	Safety of machinery - Basic concepts, general principles of design
EN ISO 13857 : 2019	Safety of machinery - Safety distances to prevent hazard zones being reached by the upper and lower limbs
EN 1012-1 : 2010 EN 1012-3 : 2013	Compressors - Safety requirements - Part 1 and Part 3
EN ISO 2151 : 2008	Acoustics - Noise test code for compressors and vacuum pumps - Engineering method (grade 2)
EN 60204-1 : 2018	Safety of machinery - Electrical equipment of machines - Part 1: General requirements
EN IEC 61000-6-2 : 2019	Electromagnetic compatibility (EMC) - Generic standards. Immunity for industrial environments
EN IEC 61000-6-4 : 2019	Electromagnetic compatibility (EMC) - Generic standards. Emission standard for industrial environments

Legal person authorized to compile the technical file and importer in the UK
(if the manufacturer is not located in the UK):

Busch (UK) Ltd
30 Hortonwood
Telford - UK

Maulburg, 02.01.2024



Dr. Martin Gutmann
General Manager
Busch Produktions GmbH

Notes

Grid area for notes.

Grid of dots for notes.

Grid of dots for notes.

Busch Vacuum Solutions

With a network of over 60 companies in more than 40 countries and agencies worldwide, Busch has a global presence. In every country, highly competent local personnel delivers custom-tailored support backed by a global network of expertise. Wherever you are. Whatever your business. We are there for you.



● Busch companies and Busch employees ● Local representatives and distributors ● Busch production site

www.buschvacuum.com