

COBRA

Dry Screw Vacuum Pumps BC 1001 G

Instruction Manual





Table of Contents

1	Prefa	nce					
	1.1	Congratulations on your purchase					
2	Prod	uct Description					
	2.1	Use					
	2.2	Operating Principle					
		2.2.1 COMBI					
		2.2.2 Gas Flow Checks					
	2.3	Oil Circuit					
	2.4	Cooling					
	2.5	Nitrogen System					
	2.6	Optional Functions/ Use of Available Accessories					
	2.7	On/ Off Switch					
	2.8	Versions					
3	Safet	:y					
	3.1	Intended Use					
	3.2	Safety Information					
	3.3	Safety Stickers					
	3.4	Sound Pressure Emission					
	3.5	Safety Area					
	3.6	Electrical Safety					
	3.0	3.6.1 Types of Electrical Work					
		3.6.2 Lock Out/ Tag Out Procedure (Type 1 of Electrical Work)					
		3.6.3 Emergency Off Circuit Description					
		3.6.4 Safety Lockout Procedure					
		3.6.5 Lock Out/ Tag Out for Hydraulics and Pneumatics					
		3.6.6 Lock Out/ Tag Out Procedure (Type 1 of Electrical Work)					
	3.7	Safety Interlock Table					
	3.8	Seismic Zone Installation					
	3.9 Information over Lubricants						
		3.9.1 Oil					
	3.10	Decommissioning Procedure					
4	Tran	sport					
	4.1	Transport in Packed State					
	4.2	Transport in Unpacked State					
5	Stora	age					
	5.1	Temporary Storage					
	5.2	Vacuum Pump Removal					
	5.3	Preservation					
		5.3.1 Start-up of the Vacuum Pump after Storage					
6	Insta	ıllation and Commissioning					
	6.1	Installation Prerequisites					
		6.1.1 Local Installation					
		6.1.2 Dimensional Drawing					
		6.1.3 Inlet Connection					
		6.1.4 Discharge Connection					
		6.1.5 Cooling Water Connection					
		6.1.7 Electrical Connection/ Checks					
		The second confection checks and the second confection control confection control cont					

	6.2	Installation	25
		6.2.1 Mounting	25
		6.2.2 Electrical Connection	26
			28
		· ·	28
		· · · · · · · · · · · · · · · · · · ·	28
		5 5	31
			31
		6.2.8 Operating Parameters Saving	32
	6.3	'	32
		' '	32
		6.3.2 Switching the Vacuum Pump On/ Off	34
7	Main	tenance	36
	7.1	Maintenance Schedule	37
			38
			39
	7.2		39
		3	39
			40
		7.2.3 Oil Color Inspection	41
		7.2.4 Oil Change	41
	7.3	Additional Checking	44
8	Over	haul	46
9			47
_	9.1		-7 47
	9.2		۰, 47
		-	
	9.3	·	48
10	Spar	e Parts	49
11	Trou	bleshooting	50
12	Oil T	ype/ Quantity	52
	12.1	Oil Type	52
	12.2	· · · · · · · · · · · · · · · · · · ·	52
13	Tech	nical Data	53
14	EU D	eclaration of Conformity	54
15	UK D	eclaration of Conformity	55

1 Preface

1.1 Congratulations on your purchase

Congratulations on your purchase of the Busch vacuum pump. With watchful observation of the field's requirements, innovation and steady development Busch delivers modern vacuum and pressure solutions worldwide.

These operating instructions contain information for

- product description,
- safety,
- transport,
- storage,
- installation and commissioning
- maintenance,
- overhaul and
- troubleshooting

of the vacuum pump.


For the purpose of these instructions, "handling" the vacuum pump means the transport, storage, installation, commissioning, influence on operating conditions, maintenance, troubleshooting and overhaul of the vacuum pump.

Prior to handling the vacuum pump these operating instructions shall be read and understood. If anything remains to be clarified, please contact your Busch representative.


Keep these operating instructions and, if applicable, other pertinent operating instructions available on site.

Product Description 2

COBRA BC 1001 G




Descriptio	Description				
IN	Inlet connection	OUT	Discharge connection		
CWI	Cooling water inlet connection	CWO	Cooling water outlet connection		
DGC	Dilution gas connection	EB	Lifting eyebolt		
ECO	Electrical connection	ESS	Emergency stop switch		
EX	Ventilating duct	MSB	Main switch button		
OSG 1	Oil sight glass DP	OSG 4	Oil sight glass DP		
PLC	PLC box	PRV	Pressure regulating valve		
RC	Remote control	RF	Radial fan		




Description	Description					
IN	Inlet connection	OUT	Discharge connection			
CWM	Cooling water flow meter	CWR	Cooling water regulating valve			
DGR 1 Regulating valve, dilution gas (middle of cylinder)		DGR 2	Regulating valve, dilution gas (middle of cylinder)			
ESS	Emergency stop switch	FME	Dilution gas flow meter			
MOT 1	Motor (DP)	MOT 2	Motor (MB)			
MV	Magnet ventil	ODP	Oil drain plug (MB)			
OFP	Oil fill plug (MB)	OFP	Oil fill plug (MB)			
OSG 1	Oil sight glass (DP)	OSG 3	Oil sight glass (MB)			
OSG 4	Oil sight glass (MB)	PLC	PLC box			
PSA	Pressure sensor	RC	Remote control			
TS 3	Oil temperature sensor (MB) klixon	TS 4	Temperature sensor PT100			
VSD 1	Variable speed drive (DP)	VSD 2	Variable speed drive (MB)			

Process Gas Diagram




Description	Description				
1	Process gas inlet	2	Process gas outlet		
3	Cooling water inlet	4	Cooling water outlet		
5	Cooling water regulating valve (CWR)	6	Cooling water flow meter (CWM)		
7	Magnetic valve (MV), regulating valve with soleneoid valve, dilution gas	8	Motor DP (MOT 1)		
9	Motor klixon (TS 2)	10	Motor MB (MOT 2)		
11	Nitrogen flow meter, dilution gas (FME)	12	Nitrogen pressure reducer (PRV)		
13	Nitrogen supply	14	Oil sight glass DP (OSG 1)		
15	Oil sight glass DP (OSG 2)	16	Oil sight glass MB (OSG 3)		
17	Oil sight glass MB (OSG 4)	18	Pressure sensor (TS 1)		
19	Pressure sensor (PSA)	20	Regulating valve, dilution gas (DGR 1)		
21	Regulating valve, dilution gas (DGR 2)	22	Temperature sensor PT100 (TS 4)		
23	Variable speed drive DP (VSD 1)	24	Variable speed drive MB (VSD 2)		
25	Oil temperature switch (MB) klixon (TS 3)				

COBRA NW 0090 A



Description				
1	Inlet	2	Outlet	
3	Oil	4	Cooling water	
5	Barrier gas	6	Screw rotors	
7	Intake medium	8	Cooling water	
9	Motor klixon			

PUMA WY 0701 B



Description	Description				
1	Oil	2	Booster lobe		
3	Motor klixon	4	Inlet		
5	Outlet	6	Cooling water		

2.1 Use

The COBRA BC vacuum pumps are designed for use in the field of microelectronics and similar in-

They can be used to draw gases and gas mixtures.



When using toxic, inflammable and/or explosive gases, make sure that the system corresponds in design to applicable local and national safety regulations and that all applicable safety measures are followed.

All product-specific safety regulations must be observed.

Solid particles must not get into the vacuum pump. Procedural errors can result in the vacuum pump drawing in a certain quantity of liquid. If the vacuum pump has drawn in liquid, a short drying time is necessary at the end of the procedure.

The allowed maximum inlet gas temperature depends on the inlet pressure and the type of gas: the lower the inlet pressure (Pa), the higher the drawn gas temperature (TGas) can be.

The following indicative values for air can be considered:

- Pa > 50 mbar, TGas < 80°C
- Pa < 50 mbar, TGas < 200°C

The vacuum pump is intended for use in a potentially non-explosive environment.

Make sure that the maximum permissible number of starts does not exceed 6 starts per hour. Those starts should be spread within the hour.

As far as temperature is concerned, the vacuum pump is suitable for evacuation of a 300 liters tank. The vacuum pump is not suitable for continuous duty at a pressure more or equal than 150 (hPa)

Caution, the operating cycle of 150 (hPa) mbar must not exceed more than 5 min. For other applications, contact your Busch representative.

- Maximum inlet pressure: 1 bar (abs).
- With pump running at full speed, do not expose to inlet pressure 300 (hPa) mbar.

The vacuum pump is tight down to ultimate pressure.

2.2 **Operating Principle**

2.2.1 **COMBI**

The COBRA BC 1001 G vacuum pumps are a combination of a screw vacuum pump NW 0090 A (DP) and a Booster vacuum pump WY 0701 B (MB). The COMBI vacuum pumps are streamlined.

The COBRA BC vacuum pumps are COBRA NW screw vacuum pumps with cooling water and nitrogen circuits.

The COBRA NW screw vacuum pumps are driven by water-cooled motors.


2.2.1.1 **Principle of DP Vacuum Pumps**

The COBRA NW screw vacuum pumps work by the principle of spiral pumps. Two parallel screws rotate in opposite directions in the pump body. Entering gases are trapped between the flights of the screws and the pump body. The gases are conveyed by the rotation of the screws to the exhaust, where they are discharged.

2.2.1.2 Principle of MB Vacuum Pumps

The Booster vacuum pumps operate according to the approved principle of the Booster type machine. Operation is both simple and effective. Two lobes with identical profiles rotate in opposition directions within a casing. As they rotate, gas is drawn into the space between each lobe and the casing where it is trapped and by the rotation pushed out into the discharge. This action is repeated twice for each revolution of each lobe and therefore four times for each revolution of the drive shaft. There is no mechanical contact between lobes and cylinder. So no oil lubrication is required.

The drive motor of Booster vacuum pump is a water-cooled canned motor.



Description			
1	Lobes	2	Housing

2.2.2 Gas Flow Checks

A pressure sensor PSA at the discharge monitors the discharge pressure. If the pressure reaches more than the limit value (alarm, preset at the factory: 0.2 bar), the purge cycle starts.

2.3 Oil Circuit

Since the complete operating principle works without contact, no oil circuit is needed in the work area.

2.4 Cooling

The vacuum pump is cooled by:

- A direct cooling water circuit in the cylinder and the motor. The cooling water flow is preset at 3 4 l/min at factory and can be adjusted with valve CWR. This cooling water circuit is used to cool the motor of the vacuum pump, the variable speed drive(s) (VSD 1, VSD 2...) and also the body of the NW vacuum pump.
- a direct cooling water circuit in the rear bearing (for exceptionally cool running in option).



NOTE

The COBRA BC vacuum pumps are principally dispatched with oil and cooling liquid already in the vacuum pump but, without cooling water. Before vacuum pump first startup, control the oil level and the cooling liquid level. In the event of absence of one or the other of these lubricants, please carry out the filling (please refer to the various chapters of filling). Do not forget to connect the cooling water supply before the first startup. Operation without these coolants can result in damage to the vacuum pump.

2.5 Nitrogen System

The nitrogen system can be used in a number of different ways:

- Nitrogen is used as dilution gas. It is injected inside the cylinder on two different places. Nitrogen flow injected in the middle hole is preset at 2 l/min and can be adjusted with valve DGR 1, depending on the application. Nitrogen flow injected in the hole on cylinder end-plate side is preset at 10 l/min and can be adjusted with valve DGR 2, depending on the application. When flow is too low a warning then an alarm signal is generated by flowmeter FME to the PLC. Status of the pump depends on the alarm function set by user (factory setting: None, pump continues running with an alarm). Dilution improves the screws functioning, especially when drawing corrosive gases.
- Nitrogen is used as sealing gas. The nitrogen is injected between the transmission and the process gas to achieve good closeness. The nitrogen flow used for the sealing is set by two chips (ϕ). With a pressure of 1,5 bar, the flow is around 8 - 10 l/min.

Optional Functions/ Use of Available Accessories 2.6

A pressure sensor (PSA) mounted at the exhaust, controls the overpressure at the exhaust. If overpressure is above 0.2 bar, pressure sensor gives a warning then an alarm signal. Status of the pump depends on the alarm function set by user (factory setting: None, vacuum pump continues running with an alarm).

A temperature sensor PT100 (TS 4) mounted on the cylinder, measures the temperature inside the cylinder (DP).

A silencer or sound absorber (accessory) at the exhaust reduces the noise of the vacuum pump and collects any condensate.

A leak-protection non-return valve (optional) at the exhaust traps the condensate in the vacuum pump when the vacuum pump is switched off.

The LCD controller processes the data of the sensors as follows:

- PSA: exhaust pressure
- TS 4: temperature inside the cylinder DP
- MOT 1 and MOT 2: DP and MB current and speed
- FME: nitrogen flow rate, dilution
- CWM: cooling water flow rate in motors/ transmission / variable speed drives

See "Installation and Maintenance Instructions, Busch PLC and Busch LCD (No. 0870758077)".

2.7 On/ Off Switch

The vacuum pump is delivered with a circuit breaker. The function start/ stop can be done in Local by using the LCD controller or in Remote by the production machine.

2.8 Versions

Further vacuum pump descriptions state the nominal displacement and the design level.

Example: BC 1001 G BC = standard version $1001 = 870 \text{ m}^3/\text{h}$ G = Design

3 Safety

3.1 Intended Use

DEFINITION: To rule out any misunderstanding, the term "handling" of the vacuum pump covers transport, storage, installation, and operation of the pump as well as effects on operating states and troubleshooting on the vacuum pump.

The vacuum pump is intended for industrial use. It may only be operated by qualified personnel.

The different application possibilities and limit values for operation described in "Product description" and "Installation requirements" must be observed by the manufacturer of the system into which the vacuum pump is to be integrated and by users.

The need for personal safety regulations depends in principle on the type of use. The operator must provide the users with the necessary means and must inform his personnel about the dangers emanating from the processed product.

The operator of the vacuum pump must observe the safety regulations and must train and instruct his personnel accordingly.

Local regulations regarding the motors and electric control elements must be observed when installing the pump in potentially explosive environments.

The maintenance instructions must be followed and observed.

These installation and maintenance instructions must be read and understood before the vacuum pump is used. If you have any doubts, contact your Busch representative.

3.2 Safety Information

The vacuum pump is designed and manufactured in compliance with the latest technical standards and safety regulations. Nevertheless, an element of residual risk remains.

This instruction manual highlights potential hazards where appropriate. Safety notes and warning messages are tagged with one of the keywords DANGER, WARNING, CAUTION, NOTICE and NOTE as follows:



DANGER

... indicates an imminent dangerous situation that will result in death or serious injuries if not prevented.



WARNING

... indicates a potentially dangerous situation that could result in death or serious injuries.




CAUTION

... indicates a potentially dangerous situation that could result in minor injuries.



NOTICE

... indicates a potentially dangerous situation that could result in damage to property.




... indicates helpful tips and recommendations, as well as information for efficient and trouble-free operation.



The COBRA BC system includes provision for the secondary containment of liquids leaks such as water and oil.


3.3 Safety Stickers

COBRA NW 0090 A




Description			
1	Warning! Hot surface! Do not touch!	2	Warning! Hot surface! Do not touch!

PUMA WY 0701 B



Descrip	otion	
1	Warning! Hot surface! Do not touch!	

COBRA BC 1001 G



3.4 Sound Pressure Emission

Refer to the table "Technical data" for the permissible sound levelling free field conditions according to EN ISO 2151.





The sound level of the vacuum pump within a certain perimeter of the vacuum pump is high. Risk of hearing damage.

Users who are spending a longer period in the vicinity of a non-insulated vacuum pump must wear suitable ear protection.

3.5 Safety Area

Before any maintenance action, ensure a safety perimeter of a least 610 [mm] around the vacuum pump. Before any maintenance action, ensure a safety perimeter of a least 610 [mm] around the vacuum pump.

3.6 Electrical Safety

3.6.1 Types of Electrical Work

The following are the four types of electrical work defined by the SEMI S2, latest version, guideline:

Type 1

Equipment is fully deenergized.

Type 2

Equipment is energized. Energized circuits are covered or insulated.

NOTE: Type 2 work includes tasks where the energized circuits are or can be measured by placing probes through suitable openings in the covers or insulators.

Type 3

Equipment is energized. Energized circuits are exposed and inadvertent contact with uninsulated energized parts is possible. Potential exposures are no greater than 30 volts rms, 42.4 volts peak, 60 volts dc or 240 volt-amp in dry locations.

Type 4

Equipment is energized. Energized circuits are exposed and inadvertent contact with uninsulated energized parts is possible. Potential exposures are greater than 30 volts rms, 42.4 volts peak, 60 volts dc, or 240 volt-amp in dry locations. Potential exposures to radio-frequency currents, whether induced or via contact, exceed the limits in Table A5-1 of Appendix 5 (SEMI S2 guideline).

3.6.2 Lock Out/ Tag Out Procedure (Type 1 of Electrical Work)

- Stop the pump with the LCD controller (press on STOP button during 10s).
- Press on emergency stop button.
- Switch off the main circuit breaker.
- Switch off the customer's power supply.
- Switch off the water and nitrogen quick connections (inlet first, then outlet).
- Put the label or warning board "Maintenance processing" on or next to the vacuum pump.

3.6.3 Emergency Off Circuit Description

- The Emergency off circuit may be opened by pressing on emergency stop button. If this element occurs, then the DP and MB vacuum pumps will immediately stop. The PLC will remain energized to save the pump status.
- If the emergency stop button was pressed, check the startup of the pump then release this button to restart the pump. Press on Start button on the LCD controller, the pump will restart.

3.6.4 Safety Lockout Procedure

- Take off the label or warning board "Maintenance processing".
- Check the cooling liquid and oil levels according to the chapters "Checking the oil level" and "Checking the cooling liquid level".
- Close the cover.
- Switch on the main disconnect switch.
- Release the emergency stop button.
- Switch on the water (outlet first, then inlet) and nitrogen guick connections.
- Start the pump with the remote control (press on START button) or with the Start / Stop button.

3.6.5 Lock Out/ Tag Out for Hydraulics and Pneumatics

- Hydraulics: cooling water.
- Pneumatics: nitrogen.

3.6.6 Lock Out/ Tag Out Procedure (Type 1 of Electrical Work)

- Stop the pump with the remote control (press on STOP button during 10s) or with the Start / Stop button (press it during 2s).
- Press on emergency stop button.
- Switch off the main disconnect switch.
- Switch off the customer's power supply.
- Switch off the water (inlet first, then outlet) and nitrogen quick connections.
- Put the label or warning board "Maintenance processing" on or next to the pump.

The end user is responsible for providing energy isolation capabilities on the water and nitrogen.

3.7 Safety Interlock Table


Interlock event	Sensor	Response	
Motor overcurrent	Variable speed drive (VSD)	Variable speed drive default and remove power to motor.	S
Motor overtempera- ture (t° > 150°C)	Temperature switch TS (klixon)	Contactors open and remove power to motors.	S
Exhaust overpressure (option)	Pressure sensor PSA	Depends on alarm function set in the PLC for overpressure Set at factory: None ie. the vacuum pump continues running with alarm.	S
Cylinder overtempera- ture (option)	Temperature switch TSA	Depends on alarm function set in the PLC for cylinder temperature. Set at factory: General Stop ie. the contactors open and remove power to motors.	S
Cooling water flow too low	Water flow meter FME	Depends on alarm function set in the PLC for water flow. Set at factory: General Stop ie. the contactors open and remove power to motors.	S

H= Hardware, S= Software

3.8 Seismic Zone Installation

Upon receipt, the vacuum pump is fixed on the transport pallet with two brackets.

- Convey the vacuum pump to its final location with a pallet truck before removing it from its support.
- Unscrew the fixing screws of the vacuum pump on the transport pallet and remove the machine from its support with an appropriate lifting system by using the lifting brackets made for this purpose.



Description			
1	Wheel	2	Adjusting nut
3	Wheel	4	Adjusting nut

Descrip	otion	
5	Lifting eye bolt	

- The vacuum pump must not lay only on the brackets. Unscrew the four adjusting nuts until the machine legs touch the ground.
- Check that the wheels no longer touch the ground.



The vacuum pump is fixed to the ground with four M10 screws, two screws per bracket. The fixing screw must stand a 1200 N tensible force (per bracket).

The final user must adapt the type of screws depending on the ground material.

3.9 Information over Lubricants

3.9.1 Oil

Oil filling	NW 0090 A	WY 0701 B
Oil quantity (Liter)	0.12	1.4
Oil type	Busch YLC 250 B, Art. No. 0831 131 400 (0,5 l ≈ 1 kg)	

• Replacement: After 16000 h (see "Maintenance Schedule [→ 37]").

3.10 Decommissioning Procedure

When the product arrives at the end of the lifetime, it is necessary to proceed to the decontamination of the vacuum pump.



Only authorized personnel may carry out any dismantling on the vacuum pump. Before work begins, the operator of the vacuum pump must fill in a form or a "Declaration Regarding Contamination of Vacuum Equipment and Components" that provides information on possible dangers and appropriate measures.

If this form has not been filled in completely and signed by a responsible person, the vacuum pump may not be dismantled.

- Proceed to disassembly of the vacuum pump. Please make sure to wear a personal protective equipment (PPE) prior to any intervention on the vacuum pump. Some residues may remain inside.
- Proceed to decommissioning of the different parts according to the current local and national laws.

4 Transport

The COBRA BC vacuum pumps are tested and checked in our factory before careful packing. Check the packaging for transport damage when the goods arrive. The vacuum pump can withstand temperatures between -25°C and +55°C during transport.

4.1 Transport in Packed State

Packed on a pallet, the vacuum pump can be moved with a hand forklift truck.

4.2 Transport in Unpacked State

The vacuum pump is fastened to the pallet with fixing pins:

• Unscrew the fastening nuts underneath the pallet.





Do not work, walk, or stand under suspended loads.





Please check out the weight of the vacuum pump before lifting it up (see "Technical Data"). Use adequate lifting gear for this.



NOTE

The eyebolts are fitted more or less at equal distance from the center of gravity of the vacuum pump incl. drive motor. If any accessories that could upset the balance of the vacuum pump, are installed, or if the vacuum pump is delivered without drive motor, it is necessary to add a belt or rope at a suitable point when lifting the vacuum pump.

- Attach lifting gear securely to the eyebolt or eyebolts.
- Use lifting gear with a crane hook equipped with safety latch.
- Lift the vacuum pump.



In case the vacuum pump was bolted to a pallet with fixing bolts:

• Unscrew the fixing bolts in the base frame.



In case of a vacuum pump filled with oil, make sure that by lifting the inclination angle of the vacuum pump do not exceed 5° from the horizontal. In case of too high inclination (>5°), risk of oil leak within the work area.

• Make sure before every transport using the appropriate lifting mean that the inclination of the vacuum pump is less than 5°.

The packaging material must be disposed of in accordance with local and national regulations.

This handbook is contained in the delivery package.

5 Storage

5.1 Temporary Storage

- Make sure that the intake and exhaust flanges are closed (put on the protective caps included in the delivery package of the vacuum pump)
- Store the vacuum pump:
 - if possible, the vacuum pump should be stored in its original packaging,
 - indoors,
 - dry,
 - in a dust-free and vibration-free room.

5.2 Vacuum Pump Removal

Before starting a vacuum pump that has been stored outside the building for a while, the vacuum pump must be moved to a room with ambient temperature, where it should rest for a day.

5.3 Preservation

If the vacuum pump will be exposed to unfavorable ambient conditions (for example, aggressive environment, frequent temperature changes), begin immediately with preservation work on the vacuum pump.

In the case of favorable ambient conditions, perform preservation work on the vacuum pump if a storage period of more than three months is planned.

• Make sure that all openings are hermetically sealed; use adhesive tape to fasten loose parts (seal rings, flat seals, etc.).



NOTE

VCI is the abbreviation for "volatile corrosion inhibitor". The VCI molecule is an organic corrosion inhibitor in the vapor phase. Integrated in various carriers such as film, cardboard, paper, foam, liquid and powder, it protects the parts against corrosion because of its action in the vapor phase. However, VCI packaging can attack synthetic surfaces and surfaces of other elastomers. If in doubt, please contact your nearest distributor. VCI packaging provides several years of protection against corrosion, even under the harshest of conditions: overseas shipment, extended storage before use.

- Wrap the vacuum pump in a VCI film.
- Store the vacuum pump:
 - if possible, the vacuum pump should be stored in its original packaging,
 - indoors,
 - dry,
 - in a dust-free and
 - vibration-free room.

5.3.1 Start-up of the Vacuum Pump after Storage

- Make sure that all protective elements, stoppers, or adhesive tapes attached before preservation have been removed.
- Switch on the vacuum pump in the sequence described in "Installation and Commissioning [→ 21]".

Installation and Commissioning 6

Installation Prerequisites 6.1



In case of non-compliance with the installation prerequisites, particularly in case of insufficient cooling:

Risk of damage or destruction of the vacuum pump vacuum pump and its components! Risk of personal injury!

The installation prerequisites must be complied with.

Please ensure that the integration of the vacuum pump is compliant with the safety requirements of the Machine Directive 2006/42/EC (concerning the responsibility of the system's manufacturer into which the vacuum pump is to be incorporated, please also refer to the note in the EU-Declaration of Conformity).





Local regulations regarding the motors and electric control elements must be observed when installing the vacuum pump in potentially explosive environments.

Make sure before start-up that all safety measures have been followed.

6.1.1 **Local Installation**

- Make sure that the environment of the vacuum pump is not potentially explosive.
- Make sure that the following ambient conditions are fulfilled:

Ambient conditions	Requirements
Ambient temperature	0 40 °C (32 104 °F).
Ambient pressure	Atmosphere
Humidity range	20 to 95%
Altitude	Up to 1000 m

• Make sure that the cooling water fulfills the following requirements:

Hardness	dGH	< 5 °
Temperature	°C	10 - 25
Overpressure	bar (rela- tive)	2 - 5
Approximate flow rate for the standard version	l/ min	3 - 4 l/min
Approximate flow rate for other applications	l/ min	3 - 4 l/min
Properties	Clean & clear	
Particle size	μm	< 200
Chloride	mg/l	< 100
Electrical conductivity	μS/cm	≤ 100
Free chloride	mg/l	< 0.3

NOTE

1° (german degree = 1° dGH) = 1,78° (french degree) = 1,25 e (english degree) = 17,9 mg/kg Ca-CO3 (american hardness).

- Make sure that the cooling water is neutral and clean.
- Make sure that the cooling water outlet is unpressurised.
- Make sure that the nitrogen fulfills the following requirements:

Overpressure	bar	1,5
Approximate flow rate	l/ min	10 - 22 l/min

- Make sure that the ambient conditions correspond to the protection class of the motor (according to nameplate).
- Make sure that the vacuum pump is placed on or fastened to a horizontal surface.
- Make sure that the vacuum pump is level.



NOTE

The pump levelling is facilitated by the adjustment stroke (~30 mm) of the four machine foots.

• Make sure that the four rollers do not touch the ground.



NOTE

In order to ensure the pump fixation to the ground, it is possible to use again the four yellow brackets that were removed at the machine reception.

- Make sure that the vacuum pump is at least 1 m away from any wall to ensure good cooling.
- Make sure that the vacuum pump is easily accessible and that the selected installation site fulfills the requirements for assembly/dismantling.
- Make sure that no temperature-sensitive parts (for example, of plastic, wood, cardboard, paper, electronic parts) come into contact with the hot surfaces of the vacuum pump.
- Make sure that the installation site or assembly area is ventilated in such a way that adequate cooling of the vacuum pump is ensured.





The surface temperature of the vacuum pump can exceed 50°C when the vacuum pump is in operation.


Danger of burns!

- Make sure that no-one can touch the vacuum pump accidentally. If necessary, attach safeguard.
- Make sure that the oil sight glasses (OSG) are easily accessible.

If oil changes are to be made on site:

• Make sure that the oil drain and oil filler are easily accessible.

Dimensional Drawing 6.1.2



Descri	Description				
1	Inlet DN 100 ISO-K	2	Outlet DN 40 ISO-KF		
3	Remote control (moveable)	4	Ventilating duct (diameter 50.8)		
5	Nitrogen inlet 1/4"	6	Cooling water outlet 3/8"		
7	Pressure regulator	8	Pressure gauge		
9	PLC control panel layout	10	Power connector		
11	Emergency stop	12	Oil sight glass (MB)		
13	Interrupter main	14	Oil sight glass (DP)		
15	Busch PLC	16	Cooling water inlet 3/8"		

- Make sure that the vacuum pump is at least 1 meter away from any wall to ensure good cooling.
- Before any maintenance action, ensure a safety perimeter of at least 610 [mm] around the vacuum pump.

6.1.3 **Inlet Connection**

• Make sure that the protection that was attached to prevent penetration of particles during transport has been removed before the vacuum pump is connected to the vacuum line



Do not put hands into the inlet aperture! Risk of body damage!



The intake of liquids or solid particles can lead to the destruction of the vacuum pump.

- Make sure that a filter or protective grating is installed at the extraction point.
- Make sure that the nominal diameter of the intake line is at least equal to the diameter of the intake flange of the vacuum pump to prevent a drop in the performance of the vacuum pump in the case of a smaller cross-section
- Make sure that the vacuum pump is connected with leakproof lines.



When the intake lines have been connected, make sure that the system does not leak. Leakages of dangerous substances must be prevented!

- Make sure that the intake lines are equipped with a shut-off device upstream of the intake flange so that the flow of drawn gas can be stopped.
- Make sure that the intake lines do not exercise any force on the intake flange. Mount bellows if necessary.
- The inlet flange has the following dimension:
- DN 100 ISO-K

In the case of long intake lines, the line cross-section should be larger than the intake flange to prevent a drop in the performance of the vacuum pump. If you have any doubts, contact your Busch representative.

6.1.4 Discharge Connection

• Make sure that the protection that was attached to prevent penetration of particles during transport has been removed before the vacuum pump is connected to the vacuum line



CAUTION

Do not put hands into the outlet aperture!

Risk of body damage!

The following instructions for connection to the discharge only apply if the drawn gas is discharged by the vacuum pump into a suitable environment.

- Make sure that the protection that was attached to prevent penetration of particles during transport has been removed before the vacuum pumpis connected to the vacuum line.
- Make sure that the nominal diameter of the exhaust line is at least equal to the diameter of the
 exhaust flange of the vacuum pump to prevent a drop in the performance of the vacuum pump
 in the case of a smaller cross-section
- Make sure that the vacuum pump is connected with leakproof lines.



When the discharge lines have been connected, make sure that the system does not leak. Leakages of dangerous substances must be prevented!

- Make sure that the discharge line is mounted in such a way that condensate cannot penetrate into the vacuum pump (siphon trap, gradient).
- Make sure that no shut-off devices are mounted in the discharge line.

- Make sure that the discharge lines do not exercise any force on the discharge flange. Mount bellows if necessary.
- The discharge flange has the following dimension:
- DN 40 ISO-KE

In the case of long discharge lines, the line cross-section should be larger than the discharge flange to prevent a drop in the performance of the vacuum pump. If you have any doubts, contact your Busch representative.

6.1.5 **Cooling Water Connection**

The cooling water is generally connected with a hose (leakproof against oxygen). The cooling water outlet must be unpressurised.

Connection diameter	│ 3/Q NIDT
Connection diameter	3/6 INF I

Nitrogen Connection 6.1.6

The nitrogen is connected with a pipe (leakproof against oxygen).

Connection diameter	1/4 NPT
---------------------	---------

6.1.7 **Electrical Connection/ Checks**

- Make sure that the regulations of the Electromagnetic Compatibility Directive 2014/30/EU as well as standard EN norms, safety directives and especially local and national regulations are observed, (this is the responsibility of the manufacturer of the system into which the vacuum pump is integrated according to the EU-Declaration of Conformity).
- Make sure that the main power supply corresponds to the data on the nameplate of the motor.
- Make sure that an overload cut-out according to EN 60204-1 is provided for the motor.
- Make sure that the drive of the vacuum pump is not disturbed by any electric or electromagnetic interferences. If you have any doubts, contact your Busch representative.
- Check permissible primary voltage next to the power connection!
- Connect the supply voltage leads on the main contactor.

If the direction is wrong, an error message appears on the LCD: reverse two connection phase poles!

6.2 **Installation**

6.2.1 Mounting

- Make sure that the "Necessary installation instructions" are followed.
- Fasten or install the vacuum pump at its final installation site.

6.2.2 Electrical Connection





Risk of electrocution, risk of damage.

Electrical installation must be performed by a suitably qualified electrician who knows and follows the following regulations:

- IEC 364 or CENELEC HD 384 or DIN VDE 0100,
- IEC Report 664 or DIN VDE 0110,
- VBG 4 or corresponding national regulations on accident prevention.



CAUTION

The circuit diagrams described below conform to the standard. Other circuit diagrams might be used. This depends on the particular order and the market.

Risk of damage to the motors!

Check the connection of the motors inside the terminal box according to the circuit diagram. Motor of screw pump BC is connected at factory.




CAUTION

When connecting up the wires into the terminal box: please make sure the tightening torque of 2 Nm is adhered to and check with a calibrated torque wrench (Nuts M6).

6.2.2.1 Power Wiring Connection

Power wiring 4 poles			
1	Phase L1		
2	Phase L2		
3	Phase L3		
4	Ground		

6.2.2.2 **Power Connector on Rear Side**



Description				
1	Pump side	2	Phase L1 (Pump side)	
3	Phase L2 (Pump side)	4	Phase L3 (Pump side)	
5	Ground (Pump side)	6	Mating connectors	
7	Phase 1 (Mating connectors)	8	Phase 2 (Mating connectors)	
9	Phase 3 (Mating connectors)	10	Ground (Mating connectors)	

Protect the vacuum pump with the electrical device according to the rated current of the vacuum pump.




If the vacuum pump is operated with a motor that turns in the wrong direction, it can be destroyed, even if this is the case for only a short moment.

- Make sure that the vacuum pump is connected correctly before switching it on.
- Determine rotation sense of the motor by using a phase rotation tester.
- Press on the start button.
- Make sure that the vacuum pump draws in.
- If not, push the Emergency stop button.

If the direction of rotation must be changed:

• Exchange two of the three feeder leads.

6.2.3 Equipment Connections (with Options)



Descri	Description				
1	LCD serial wiring (RJ45), LCD 1	2	LCD serial wiring (RJ45), LCD 2		
3	PC serial wiring (9 poles) (option)	4	USB connection		
5	Customer Network, Communication modbus RTU RS 232	6	Ethernet network connection (Busch Monitoring System - Option)		
7	Interface connection (50 poles) (option)	8	PID Interface (option)		

The information concerning the use of the Busch PLC and the Busch LCD (RC) can be found in the Operation and Maintenance manual (Art. No. 0870758077).

6.2.4 Connection of Lines/ Pipes

- Connect the intake lines.
- Connect the discharge lines.
- Make sure that all caps, safeguards, and similar covers are mounted.
- Make sure that the inlet and outlet for the cooling air are not covered or closed and that the flow of cooling air is not impaired in any way.

6.2.5 Oil Filling



NOTE

The COBRA BC vacuum pumps are generally dispatched with oil already in the vacuum pump. Before vacuum pump first startup, control the oil level.


In the event of absence of one or the other of these lubricants, please carry out the filling (see "Oil Type/ Quantity [\rightarrow 52]" for information on the recommended oils).

• Prepare the quantity of oil specified in the table "Oil Quantity [→ 52]".

Oil filling	NW 0090 A	WY 0701 B
Oil quantity (Liter)	0.12	1.4
Oil type	Busch YLC 250 B, Art. No.	0831 131 400 (0,5 l ≈ 1 kg)


COBRA NW 0090 A Oil Filling 6.2.5.1

• Unscrew the oil filler plugs (OFP).




Description				
1	Oil fill plug (OFP)	2	Oil drain plug (ODP)	
3	Oil sight glass (OSG)			

Fill up to the upper level of the target circle of the oil sight glasses (OSG). Make sure that the filling level is in the target circle of the oil sight glasses (OSG).



Make sure that the seal ring in the oil filler plugs is not damaged, replace plugs if necessary. Fit the oil filler plugs and tighten up.

6.2.5.2 PUMA WY 1251 C Oil Filling



Description				
1	Oil fill plug (OFP)	2	Oil fill plug (OFP)	
3	Oil sight glass (OSG)	4	Oil drain plug (ODP)	
5	Oil sight glass (OSG)	6	Oil drain plug (ODP)	



NOTE

The quantity of oil specified in the installation handbook is of informative nature only. Check the oil level with the help of the various oil sight glasses (OSG 1,2,3,4) on the vacuum pump.



Before you change the type of oil, make sure that the new type is compatible with the old type. If necessary, flush the vacuum pump.

- Unscrew the oil filler cap (OFP).
- Fill in oil.
- Make sure that the oil level lies between the MIN and MAX markings on the oil sight glasses.
- Make sure that the seals of the oil filler cap are not damaged. Replace them if necessary
- Screw on the oil filler cap hermetically tight.

NOTE

It is easier to switch on the vacuum pump with cold oil when the intake line is not closed or when the intake flange is not covered by a rubber plate.

Start the vacuum pump.

If the intake line is equipped with a shut-off device:

• Close the shut-off device.

If the intake line is not equipped with a shut-off device:

- Place a rubber plate on the intake flange.
- Let the vacuum pump run for a few minutes.
- Stop the vacuum pump and wait a few minutes.
- Make sure that the oil level still lies between the MIN and MAX markings on the oil sight glasses.

If the oil level is below the MIN marking (Booster):

• Fill in more oil.

If the intake line is equipped with a shut-off device:

• Open the shut-off device.

If the intake line is not equipped with a shut-off device:

Remove the rubber plate from the intake flange and connect the intake line to the intake flange.



In case of a vacuum pump filled with oil, make sure that by lifting the inclination angle of the vacuum pump do not exceed 5° from the horizontal.

In case of too high inclination (>5°), risk of oil leak within the work area.

Make sure before every transport using the appropriate lifting mean that the inclination of the vacuum pump is less than 5°.



The vacuum pump must remain in a horizontal position when it has been filled with oil.

6.2.6 **Direct Cooling Checking**

The flow of the cooling water is checked by the flow meter CWM. The flowmeter must be connected in such a way that switching-on leads to a warning at 2 l/min, when the flow drops below 1.5 l/min, the vacuum pump must be stopped.

6.2.7 **Nitrogen Supply Checking**

The flow of the nitrogen is checked by the flowmeter FME. The flowmeter must be connected in such a way that switching-on leads to an alarm. The alarm limit can be adjusted depending on the type of process.

6.2.8 Operating Parameters Saving

As soon as the vacuum pump is working under normal conditions after being switched on:

• Measure the working current of the motor and save it as reference value for all future maintenance and repair work.

6.3 Recommendations on Operation

6.3.1 Application



The vacuum pump is designed for use under the conditions specified here.

If these conditions are not met, there is a risk of damage to or total destruction of the vacuum pump and its components!

The vacuum pump may only be switched on under the specified conditions.

The COBRA BC vacuum pumps are designed for use in the field of microelectronics and similar industries.

They can be used to draw in gases and gas mixtures.



When using toxic, inflammable and/or explosive gases, make sure that the system corresponds in design to applicable local and national safety regulations and that all applicable safety measures are followed.

All product-specific safety regulations must be observed.

Solid particles must not get into the vacuum pump. Procedural errors can result in the pump drawing in a certain quantity of liquid. If the vacuum pump has drawn in liquid, a short drying time is necessary at the end of the procedure.

The allowed maximum inlet gas temperature depends on the inlet pressure and the type of gas: the lower the inlet pressure (Pa), the higher the drawn gas temperature (TGas) can be.

The following indicative values for air can be considered:

Pa > 50 mbar	TGas < 80°C
Pa < 50 mbar	TGas < 200°C

The vacuum pump is intended for use in a potentially non-explosive environment.

• Make sure that the maximum permissible number of starts does not exceed 6 starts per hour. Those starts should be spread within the hour.

As far as temperature is concerned, the vacuum pump is suitable for continuous duty at any pressure between atmosphere and ultimate pressure.

As far as temperature is concerned, the vacuum pump is suitable for evacuation of a 300 liters tank. The vacuum pump is not suitable for continuous duty at a pressure more or equal than 150 (hPa) mbar.

Caution, the operating cycle of 150 (hPa) mbar must not exceed more than 5 min. For other applications, contact your Busch representative.

- Maximum inlet pressure: 1 bar (abs).
- With pump running at full speed, do not expose to inlet pressure 300 (hPa) mbar.

The vacuum pump is tight down to ultimate pressure.





The surface temperature of the vacuum pump can exceed 50 °C when the vacuum pump is in operation.

Danger of burns!

The vacuum pump may not be touched when it is in operation. If touching the vacuum pump is unavoidable, wait until the surface temperature has cooled down or wear protective gloves.



CAUTION



The sound level of the vacuum pump within a certain perimeter of the vacuum pump is high. Risk of hearing damage.

Users who are spending a longer period in the vicinity of a non-insulated vacuum pump must wear suitable ear protection.



CAUTION

The COBRA BC vacuum pumps could be delivered without oil, without cooling water and without cooling liquid.

Operation without oil will result in damage to the vacuum pump!

The vacuum pump must remain in a horizontal position when it has been filled with oil.



CAUTION

The COBRA BC vacuum pumps are always delivered without oil, without cooling water and without cooling liquid.

Operation without coolants will result in damage to the vacuum pump!



CAUTION

The COBRA BC vacuum pumps are always delivered without oil, without cooling water. Operation without coolants will result in damage to the vacuum pump!



CAUTION

The cooling water flow, which is checked by the flow meter CWM, must be at least 3 - 4 l/min .

- Make sure that all caps, safeguards, and similar covers are mounted.
- Make sure that the safeguards are switched on.
- Make sure that the inlet and outlet for the cooling air are not covered or closed and that the flow of cooling air is not impaired in any way.

- Make sure that the vacuum pump does not leak. Leakages of dangerous substances must be prevented.
- Make sure that the "Necessary installation instructions" are followed and especially that adequate cooling is ensured.

The following must be noted when the vacuum pump is shut down for a longer period of time:



If there is a risk of frost, all the cooling water must be drained out of the vacuum pump if the pump is shut down for a longer period of time!

- Drain the cooling water
 - Pull off the connections for the inlet and outlet of the cooling water.
 - Drain the cooling water completely.
 - If necessary, drain the cooling water with the help of compressed air to prevent any risk of frost or corrosion.



NOTE

When the vacuum pump has not been in operation for a few days or when a sticky substance has been drawn, it is possible that the two scroll rotors of the NW (DP) vacuum pump will stick to each other. Screw opens the access cover to the scroll rotors. Loosen the rotors from each other with the help of an Allan key by turning them in clockwise direction by hand.

6.3.2 Switching the Vacuum Pump On/ Off

6.3.2.1 First Start-up of the System

• Make sure that the "Necessary installation instructions" are followed.

If the vacuum pump is equipped with a solenoid gate valve in the cooling water circuit:

- Open the solenoid gate valve.
- Make sure that the cooling water flow is set correctly:
- The cooling water circuit (*standard) is used to cool the variators, the motors and the DP and MB cylinders. The flow regulating valve CWR of the cooling water flow is preset at 3 - 4 l/min.
- Make sure that the nitrogen flow is set correctly:
- Nitrogen is used as dilution gas. It is injected inside the cylinder on two different places. Nitrogen flow injected in the middle hole is preset at 2 l/min and can be adjusted with valve DGR1, depending on the application. Nitrogen flow injected in the hole on cylinder end-plate side is preset at 10 l/min and can be adjusted with valve DGR2.
- Switch on the vacuum pump.
 - Make sure that the vacuum pump does not leak.

If the system is equipped with a solenoid gate valve at the intake:





Do not open gate valve if booster is running at full speed (90 Hz).

Risk of primary pump damage.

- Use "Automatic Load Lock" mode or "External Signal" on tool interface to start/ stop the booster (refer to Busch PLC manual).
 - Open the solenoid gate valve.

6.3.2.2 **Switching the System Off**

If the vacuum pump is equipped with a solenoid gate valve at the intake:

- Close the solenoid gate valve.
- Switch off the vacuum pump .
- Shut off the nitrogen supply.
- Shut off the cooling water supply.

If the vacuum pump is equipped with a solenoid gate valve in the cooling water circuit:

- Close the solenoid gate valve.
- Make sure that the vacuum pump is currentless.

7 Maintenance





Live wires.

Risk of electrical shock!

• Electrical installation work must only be executed by qualified personnel.













In case the vacuum pump has conveyed gases that have been contaminated with foreign materials that are dangerous to health, the oil and condensates will also be contaminated.

These foreign materials can infiltrate the pores, recesses, and other internal spaces of the vacuum pump .

Danger to health when the vacuum pump is dismantled.

Danger to the environment.

Always wear protective clothing when carrying out maintenance work.

Before any maintenance work, the inlet and outlet piping as well as the vacuum pump itself must be flushed with nitrogen.



CAUTION

Only authorized personnel may carry out dismantling work on the vacuum pump. Before work begins, the operator of the vacuum pump must fill in a form or a "Declaration of Contamination of Vacuum Equipment and Components" that provides information on possible dangers and appropriate measures.

If this form has not been filled in completely and signed, the vacuum pump may not be dismantled.



CAUTION

Before maintenance work is started, a safety area of at least 610 [mm] around the vacuum pump must be set up.





CAUTION

The surface temperature of the vacuum pump can exceed 50 °C when the vacuum pump is in operation.

Danger of burns!

The vacuum pump may not be touched when it is in operation. If touching the vacuum pump is unavoidable, wait until the surface temperature has cooled down or wear protective gloves.

Before starting maintenance work, make sure that the vacuum pump has been switched off and that it cannot be switched on again accidentally. Follow the shutdown procedure in the section "Lock Out/ Tag Out Procedure [\rightarrow 38]" depending on the needs of maintenance:

- Stop the pump with the Remote control (RC) (press on STOP button during 10s).
- Press on emergency stop button.
- Switch off the main circuit breaker.
- Open the power box and switch off the circuit breakers.
- Switch off the customer's power supply.
- Switch off the water (inlet first, the outlet) and nitrogen quick connections.(pumps cooling is quickly done by not switching off the water connections).
- Depending on the maintenance type, let the vacuum system cool in order to avoid burn (rapid cooling of the vacuum pump wished or not).
- Put the label or warning board "Maintenance processing" on or next to the vacuum pump.





The oil temperature can reach a value of 100°C! Danger of burns!

- Make sure that the oil circuit and the coolant circuit have been emptied before moving the vacuum pump.
- Make sure that there are no cleaning tools in the vacuum pump anymore according to local and national regulations.

Before pulling off the different connections, make sure that the intake and exhaust lines of the vacuum pump correspond to atmospheric pressure

When the maintenance work has been finished, follow the procedure "Safety Lockout Procedure [**→** 39]":

- Take off the label or warning board "Maintenance Processing".
- Check the oil level according to the chapters "Oil Level Checking [→ 39]"
- Switch on the customer's power supply
- Switch on the water quick connections (outlet first, then inlet).
- Make sure that the "Necessary Installation Instructions" are followed.
- Start the vacuum pump with the Remote control (RC) (press on START button or with START / STOP button).

7.1 Maintenance Schedule

The maintenance intervals depend very much on the individual operating conditions. The intervals given below are considered as starting values which should be individually shortened or extended as appropriate.

Particularly harsh applications or heavy duty operation, such as high dust loads in the environment or in the process gas, other contamination or ingress of process material, can make it necessary to shorten the maintenance intervals significantly.

Interval	Maintenance work
Weekly	 Check the oil level, see "Oil Level Checking [→ 39]".
	• Check the cooling water flow, see "Cooling Water" in "Additional Checking [→ 44]".
	Check the vacuum pump for oil leaks - in case of leaks have the vacuum pump repaired (contact Busch).
	 Check the vacuum pump for cooling water leaks - in case of leaks have the vacuum pump repaired (contact Busch).

7.1.1 Lock Out/ Tag Out Procedure

- Stop the vacuum pump with the remote control (RC) (press on STOP button during 10s).
- Press on emergency stop button.
- Switch off the main circuit breaker.
- Switch off the customer's power supply.
- Switch off the water and nitrogen quick connections (inlet first, then outlet).
- Put the label or warning board "Maintenance Processing" on or next to the vacuum pump .

Safety Lockout Procedure 7.1.2

- Take off the label or warning board "Maintenance Processing".
- Check the cooling liquid and oil levels according to the chapter "Oil Level Checking [→ 39]".
- Close the cover.
- Switch on the main circuit breaker.
- Release the emergency stop button.
- Switch on the water and nitrogen quick connections (outlet first, then inlet).
- Make sure that the "Necessary Installation Instructions" are followed.
- Start the vacuum pump with the remote control (RC) (press on START button).

7.2 Oil Checking

7.2.1 Oil Level Checking

- Make sure that the vacuum pump has been switched off and that it cannot be switched on again accidentally.
- Make sure that the oil level still lies between the MIN and MAX markings on the oil sight glasses.

If the oil level lies below the MIN marking:


• Top up with oil (see "Refilling oil")

If the oil level exceeds the MAX marking:

- Check the condensate drain
- Drain the oil (see "Draining the oil")

Indication of the oil level on the various oil sight glasses (OSG 1,2,3,4):

Oil level, pump not operating



COBRA NS (DP) vacuum pump:

If the oil level lies below the target circle:

• Top up with oil (see "Refilling oil")

If the oil level exceeds the target circle:

- Check the condensate drain
- Drain the oil (see "Draining the oil")

Booster (MB):

 Make sure that the oil level still lies in the target circle or between the MIN and MAX markings (Booster) on the oil sight glasses.

If the oil level lies below the MIN marking:

• Top up with oil (see "Refilling oil")

If the oil level exceeds the MAX marking:

- Check the condensate drain
- Drain the oil (see "Draining the oil")

7.2.2 Oil Refilling

• Prepare the needed oil quantity, see Oil Type/ Quantity [→ 52].





WARNING



The use of chemically contaminated or polluted oil can lead to hazardous pump conditions which could cause personal injury.



NOTE

Oil does not normally have to be refilled outside the recommended oil change intervals. A drop in the oil level indicates a fault (see "Alarms and warnings -> Busch PLC and Busch LCD").



CAUTION

Only fill in oil through the oil filler opening.



NOTE

The quantity of oil specified in the Instruction Manual is of informative nature only. Check the oil level with the help of the various oil sight glasses on the vacuum pump.



CAUTION

Danger of burns when the oil filler cap is open.

Danger of injuries when the oil filler cap is not screwed on properly.

Only unscrew the oil filler cap when the vacuum pump has been switched off.

The vacuum pump may only be switched on when the oil filler cap is properly closed and tight. We recommend submitting the pump to a leakage rate test in order to ensure the pump is leak tight.

- Make sure that the vacuum pump has been switched off and that it cannot be switched on again accidentally.
- Unscrew the oil fill plug (OFP).
- Fill in oil to the middle of the oil sight glass..
- Make sure that the oil level lies between the MIN and MAX markings on the oil sight glass.
- Make sure that the seal of the oil filler cap is not damaged. Replace it if necessary.
- Screw on the oil filler cap hermetically tight.
- Unscrew the oil filler caps (OFP) of the DP and MB vacuum pumps (if necessary).
- Fill up to the upper level of the target circle of the oil sight glasses (OSG) or middle of the oil sight glass (Booster).
- Make sure that the oil level still lies in the target circle or between the MIN and MAX markings (Booster) on the oil sight glasses.
- Make sure that the seals of the filler cap are not damaged and that they sit properly. Replace them if necessary. Screw on the filler cap again.

Oil Color Inspection 7.2.3





Oil "YLC 250 B" contaminated chemically or by foreign bodies.

Risk of explosion!

If the oil becomes dark:

- Contact your Busch representative without delay.
- Make sure that the oil is either light or transparent.

If the oil becomes dark or looks different from the initial color:

• Change the oil immediately, see Oil Change.



Contact your Busch representative to find out why the oil color has changed.

7.2.4 Oil Change





DANGER









If the vacuum pump has pumped gases that were contaminated with foreign bodies that are hazardous to health, the oil is also contaminated with these foreign bodies.

There is a health hazard when changing contaminated oil. There is also a danger to the envi-

Wear protective clothing when replacing contaminated oil.

Contaminated oil must be treated specially and must be disposed of according to applicable regulations.

7.2.4.1 **Used Oil Draining**



NOTE

After switching off the vacuum pump at normal operating temperature wait no more than 20 minutes before the oil is drained.

- Make sure that the vacuum pump is switched off and cannot accidentally be switched on again.
- Make sure that the vacuum pump is vented to atmospheric pressure.

COBRA NS (DP) vacuum pump:

- Put a drain tray underneath the oil drain plugs (ODP).
- Remove the oil drain plugs (ODP).
- Carefully remove the drain plugs.

- Drain the oil.
- Because of wear and tear on the seals replace the current drain plugs with new ones.

When the oil flow has stopped:

- Close the oil drain plugs (ODP).
- Switch on the vacuum pump for a few seconds.
- Make sure that the vacuum pump is switched off and cannot accidentally be switched on again.
- Remove the oil drain plugs again and drain any remaining oil.
- Check that no metal swarf sticks to the magnet of the drain plug, clean if necessary.
- Make sure that the seals of the magnetic plug is undamaged and correctly positioned, replace if necessary.
- Refit the oil drain plugs and tighten up.
- Dispose of the used oil in compliance with applicable regulations.



CAUTION

Because the ends of the drain plugs are magnetic, metal swarf can stick to them. Always clean away this swarf when removing the drain plugs.

Because of wear and tear of the seals, it is recommended to replace the drain plugs whenever the oil is changed.

Booster (MB):

- Put a drain tray underneath the oil drain plugs (ODP).
- Unscrew the oil drain plugs (ODP).
- Drain the oil.

When the oil flow has stopped:

- Refit the oil drain plugs (ODP) again.
- Switch on the vacuum pump for a brief moment and let it run for a few seconds.
- Make sure that the vacuum pump is switched off and cannot accidentally be switched on again.
- Carefully remove the oil drain plugs (ODP) again and drain any remaining oil.
- Make sure that the seals of the drain plugs are not damaged and that they sit properly. Replace them if necessary.
- Refit the oil drain plugs (ODP) and tighten them up.
- Dispose of the used oil in compliance with applicable regulations.

7.2.4.2 New Oil Filling

COBRA NS (DP) vacuum pump:

• Prepare the quantity of oil needed (see "Oil Type/ Quantity [→ 52]").



CAUTION

The use of chemically contaminated or polluted oil can lead to hazardous pump conditions which could cause personal injury.

NOTE

The quantity of oil specified in the Instruction Manual is of informative nature only. Check the oil level with the help of the various oil sight glasses on the vacuum pump.


Make sure that the drain plugs have been fitted properly and that they do not leak.



Only fill in oil through the oil filler opening.

- Make sure that the vacuum pump has been switched off and that it cannot be switched on again accidentally.
- Unscrew the oil filler cap (OFP)

Oil level, pump not operating



- Fill up to the upper level of the target circle of the oil sight glasses (OSG).
- Make sure that the oil level still lies in the target circle of the oil sight glasses.
- Make sure that the seals of the filler cap are not damaged and that they sit properly. Replace them if necessary.
- Screw on the filler cap again.

Booster (MB):

• Prepare the quantity of oil needed (see "Oil Type/ Quantity [→ 52]").



CAUTION

The use of chemically contaminated or polluted oil can lead to hazardous pump conditions which could cause personal injury.



NOTE

The quantity of oil specified in the Instruction Manual is of informative nature only. Check the oil level with the help of the various oil sight glasses on the vacuum pump.

Make sure that the drain plugs have been fitted properly and that they do not leak.



Only fill in oil through the oil filler opening.

• Unscrew the oil filler cap (OFP)

Oil level, pump not operating







- Fill up to the upper level of the target circle of the oil sight glasses (OSG).
- Make sure that the oil level still lies in the target circle of the oil sight glasses.
- Make sure that the seals of the filler cap are not damaged and that they sit properly. Replace them if necessary.
- Screw on the filler cap again.
- Fill up to the upper level of the target circle of the oil sight glasses (OSG) or middle of the oil sight glass (Booster).
- Make sure that the oil level still lies in the target circle or between the MIN and MAX markings (Booster) on the oil sight glasses.
- Make sure that the seals of the filler cap are not damaged and that they sit properly. Replace them if necessary. Screw on the filler cap again.

7.3 Additional Checking

Subject	Checking
Cooling Water	Check the cooling water flow.
	If the flow drops, check for leaks:
	Make sure that the cooling water specifications are followed.
Nitrogen	Check the nitrogen flow.
	If the flow drops, check for leaks:
	Make sure that the nitrogen specifications are followed.
Current Consumption	Check the current intensity of the motor.
	An increased intensity is an indication for a fault (see "Trouble-shooting [\rightarrow 50]").
Silencer (Accessory)	Make sure that the condensate does not collect at the exhaust of the vacuum pump .
	Drain the condensate at the drain opening and collect it in a container.
	Dispose of the condensate according to applicable environmental protection regulations.
	Check the silencer regularly and clean it if necessary.
Leak-protection Non-return Valve (Accessory)	Check the leak-protection non-return valve regularly and clean it if necessary.









Wear protective clothing when carrying out maintenance work on the silencer and leak-protection non-return valve.

There could still be residues of contamination.

8 Overhaul



Inappropriate maintenance work on the vacuum pump can damage the vacuum pump.

Danger of explosion!

- If requirements are not met, the vacuum pump may not be switched on!
- Should work exceed the dismantling work described in this handbook, it may only be carried out by authorized persons.











The machine is contaminated with hazardous material.

Risk of poisoning!

Risk of infection!

If the machine is contaminated with hazardous material:

• Wear appropriate personal protective equipment.



NOTICE

Improper assembly.

Risk of premature failure!

Loss of efficiency!

• Any disassembly of the machine beyond that described in this manual must be carried out by technicians approved by Busch.

If the machine has conveyed gas contaminated with foreign materials which are hazardous to health:

• Decontaminate the machine as much as possible and state the contamination status in a 'Declaration of Contamination'.

The manufacturer will only accept machine accompanied by a signed, fully completed and legally binding "declaration of contamination", downloadable from the following link: buschvacuum.com/declaration-of-contamination.

Removal from Service 9





Live wires.

Risk of electrical shock!

Electrical installation work must only be executed by qualified personnel.





Hot surface.

Risk of burns!

Before doing anything that requires touching the machine, let it cool down first.





Hot liquids.

Risk of burns!

Before draining liquids, let the machine cool down first.

9.1 **Temporary Removal from Service**

Before disconnecting the intake and exhaust lines and switching off the cooling water and nitrogen lines, make sure that the lines have adjusted to atmospheric pressure.

Recommissioning 9.2



After a long period of inactivity, it is possible that the rotor screws of the COBRA NW vacuum pump are stuck.

Turn the rotor screws manually.

- Make sure that the various protective elements, stoppers, or adhesive tapes have been removed.
- Switch on the vacuum pump by following the procedure described in "Installation and Commissioning".













In case the vacuum pump has conveyed gases that have been contaminated with harmful foreign material which are harmful to health, the oil and the condensates will also be contaminated with harmful foreign material.

These foreign materials can infiltrate the pores, recesses, and other internal spaces of the vacuum pump.

Danger to health during dismantling of the vacuum pump.

Danger to the environment.

During dismantling of the vacuum pump protective equipment and clothing must be worn.

Prior to shipping, the vacuum pump must imperatively be decontaminated, and the degree of contamination must be documented in a declaration of decontamination ("Declaration of Decontamination"), which can be downloaded from www.buschvacuum.com.

Used oil and condensates must be disposed of separately in compliance with applicable environmental regulations.

When the product has reached the end of its lifetime:

• Decontaminate the vacuum pump.



CAUTION

Only authorized personnel may carry out dismantling work on the vacuum pump. Before work begins, the operator of the vacuum pump must fill in a form or a "Declaration of Decontamination" that provides information on possible dangers and appropriate measures.

If this form has not been filled in completely and signed, the vacuum pump may not be dismantled.

- Drain the oil.
- Dispose of the oil according to local environmental protection regulations.
- Begin dismantling the vacuum pump.









During dismantling of the vacuum pump protective equipment and clothing must be worn.

- Dispose of the vacuum pump as scrap metal.
- Dispose of the individual parts of the machine according to local regulations.

A lithium battery is present inside the PLC:

• Eliminate the lithium battery according to local and national regulations in place, relating to environment.

10 Spare Parts



Use of non-Busch genuine spare parts.

Risk of premature failure!

Loss of efficiency!

• Use only Busch genuine spare parts, consumables and supplies to ensure correct operation of the machine and to validate the warranty.

There are no standard spare parts kits available for this product.

For original Busch spare parts:

• Contact your Busch representative.

Troubleshooting 11





Live wires.

Risk of electrical shock!

• Electrical installation work must only be executed by qualified personnel.





Hot surface.

Risk of burns!

Before doing anything that requires touching the machine, let it cool down first.





Hot liquids.

Risk of burns!

Before draining liquids, let the machine cool down first.

Problem	Possible Cause	Remedy
The machine does not start.	The motor is not supplied with the correct voltage.	Check the power supply.
	The rotors are jammed or seized.	 Turn the screw rotors man- ually from the rotor access plug (PMR).
		• Repair the machine (contact Busch).
	Solid foreign matter has entered the machine.	 Remove the solid foreign matter or repair the ma- chine (contact Busch).
		 Install an inlet filter if necessary.
	A temperature sensor has reached the switch point.	Let the machine cool down.
		• See problem "The machine runs too hot".
	Corrosion in the machine from	Repair the machine.
	remaining condensate.	 Check the process and fol- low the recommendation in case of conveying condens- able vapors.
	The motor is defective.	Replace the motor.

Problem	Possible Cause	Remedy
The machine does not reach the usual pressure at the inlet connection.	Suction or discharge lines too long or section diameter too small.	 Use larger diameter or shorter lines. Seek advice from your local Busch representative.
	Process deposits on the pumping components	Flush the machine.
	If an inlet screen or an inlet filter is installed, it can be partially clogged.	Clean the inlet screen or re- place the inlet filter car- tridge.
	The machine runs in the wrong direction.	Check the direction of rotation, see Wiring Diagram Three-Phase Motor (Pump Drive).
	Internal parts are worn or damaged.	Repair the machine (contact Busch).
The machine runs very noisily.	Wrong oil quantity or unsuitable oil type.	Use one of the recommend- ed oils in the correct quanti- ty, see Oil.
	Defective gears, bearings or coupling element.	Repair machine (contact Busch).
The machine runs too hot.	Insufficient cooling.	Make sure to comply with the cooling water require- ments, see Cooling Water Connection.
	Ambient temperature too high.	Observe the permitted ambient temperature, see Technical Data.
	Temperature of the process gases at the inlet too high.	Observe the permitted gas inlet temperature, see Technical Data.
	The cooling water pump is defective.	Repair the machine.
	Oil level too low.	Top up oil.
The oil is black.	Oil change intervals are too long.	Drain the oil and fill in new oil, see Oil Change.
	The machine runs too hot.	See problem "The machine runs too hot".

For resolution of problems not listed in the troubleshooting table, contact your Busch representative.

12 Oil Type/ Quantity

12.1 Oil Type

Make sure that the oil type corresponds to specifications:

	YLC 250 B
ISO-VG	250
Oil Type	Synthetic
Part number 0.5 L packaging	0831 131 400
Part number 1 L packaging	0831 108 878
Part number 5 L packaging	0831 108 879

Oil suitability

• Oil YLC 250 B: Mandatory oil for specific applications.



The use of chemically contaminated or polluted oil can lead to hazardous pump conditions which could cause personal injury.

12.2 Oil Quantity

The quantity of oil specified in the following table is of informative nature only. Check the oil level with the help of the various oil sight glasses on the vacuum pump.

Quantity (l)	Motor side (A)	Inlet side (B)
NW 0090 A	0.12	-
Quantity (l)	Motor side (A)	Gear side (B)
WY 0701 B	0.6	0.8

13 Technical Data

		COBRA BC 1001 G
Nominal pumping	m³/h	870
speed	ACFM	512.0
Ultimate pressure	hPa (mbar)	0.003
	TORR	0.00225
Nominal motor rating backing pump (50 Hz)	kW	1.5
Nominal motor rating vacuum booster (90 Hz)	kW	2.9
Power consumption at ultimate pressure	kW	1.7
Power consumption at ultimate pressure / idle mode	kW	1.2
Maximal intensity Δ	А	35
Nominal motor speed backing pump (50 Hz)	min ⁻¹	3000
Nominal motor speed vacuum booster (90 Hz)	min-1	5400
Sound pressure level (ISO 2151), KpA = 3 dB *	dB(A)	60
Ambient temperature	°C	0 40
range	°F	32 104
Maximum allowable counter pressure at discharge	hPa (mbar)	200
Water consumption (motors cooling)	l/min	min. 3.0 – 4.0
Cooling water temperature	°C	10 - 25
Cooling water pressure	bar / ΔP	2 - 5
Nitrogen consumption	l/min	0 – 70
Nitrogen overpressure	bar	1.5
Weight approx.	kg	350

^{*} With silencer at exhaust.

14 EU Declaration of Conformity

This Declaration of Conformity and the CE-markings affixed to the nameplate are valid for the machine within the Busch scope of delivery. This Declaration of Conformity is issued under the sole responsibility of the manufacturer.

When this machine is integrated into a superordinate machinery the manufacturer of the superordinate machinery (this can be the operating company, too) must conduct the conformity assessment process for the superordinate machine or plant, issue the Declaration of Conformity for it and affix the CE-marking.

The manufacturer

Busch Manufacturing Korea, Ltd. 189-51, Soicheon-ro, Majang-myun Icheon-si, Gyunggi-do, 467-813 Republic of Korea

declares that the machine: COBRA BC 1001 $\,\mathrm{G}$

fulfill(s) all the relevant provisions from EU directives:

- 'Machinery' 2006/42/EC
- 'Electromagnetic Compatibility' (EMC) 2014/30/EU
- 'RoHS' 2011/65/EU Restriction of the use of certain hazardous substances in electrical and electronic equipment (incl. all related applicable amendments)

and comply(-ies) with the following harmonized standards that have been used to fulfill those provisions:

Standard	Title of the Standard
EN ISO 12100 : 2010	Safety of machinery - Basic concepts, general principles of design
EN 60204-1 : 2018	Safety of machinery - Electrical equipment of machines - Part 1: General requirements
EN ISO 13857 : 2019	Safety of machinery - Safety distances to prevent hazard zones being reached by the upper and lower limbs
EN ISO 2151 : 2008	Acoustics - Noise test code for compressors and vacuum pumps - Engineering method (grade 2)
EN IEC 61000-6-2 : 2019	Electromagnetic compatibility (EMC) - Generic standards. Immunity for industrial environments
EN IEC 61000-6-4 : 2019	Electromagnetic compatibility (EMC) - Generic standards. Emission standard for industrial environments

Legal person authorized to compile the technical file and authorized representative in the EU (if the manufacturer is not located in the EU):

Busch Dienste GmbH Schauinslandstr. 1 DE-79689 Maulburg

Icheon-si, 19.12.2023

Jeihong Kim

General Manager

Busch Manufacturing Korea, Ltd

Teihong Kim

UK Declaration of Conformity 15

This Declaration of Conformity and the UKCA-markings affixed to the nameplate are valid for the machine within the Busch scope of delivery. This Declaration of Conformity is issued under the sole responsibility of the manufacturer.

When this machine is integrated into a superordinate machinery the manufacturer of the superordinate machinery (this can be the operating company, too) must conduct the conformity assessment process for the superordinate machine or plant, issue the Declaration of Conformity for it and affix the UKCA-marking.

The manufacturer

Busch Manufacturing Korea, Ltd. 189-51, Soicheon-ro, Majang-myun Icheon-si, Gyunggi-do, 467-813 Republic of Korea

declares that the machine: COBRA BC 1001 G

fulfill(s) all the relevant provisions from UK legislations:

- Supply of Machinery (Safety) Regulations 2008
- Electromagnetic Compatibility Regulations 2016
- Restriction of the use of certain hazardous substances in Electrical and Electronic Equipment Regulations 2012

and comply(-ies) with the following designated standards that have been used to fulfill those provisions:

Standard	Title of the Standard
EN ISO 12100 : 2010	Safety of machinery - Basic concepts, general principles of design
EN 60204-1 : 2018	Safety of machinery - Electrical equipment of machines - Part 1: General requirements
EN ISO 13857 : 2019	Safety of machinery - Safety distances to prevent hazard zones being reached by the upper and lower limbs
EN ISO 2151 : 2008	Acoustics - Noise test code for compressors and vacuum pumps - Engineering method (grade 2)
EN IEC 61000-6-2 : 2019	Electromagnetic compatibility (EMC) - Generic standards. Immunity for industrial environments
EN IEC 61000-6-4 : 2019	Electromagnetic compatibility (EMC) - Generic standards. Emission standard for industrial environments

Legal person authorized to compile the technical file and importer in the UK (if the manufacturer Busch (UK) Ltd 30 Hortonwood is not located in the UK): Telford - UK

Icheon-si, 19.12.2023

Jeihong Kim

General Manager

Busch Manufacturing Korea, Ltd

Jeihong Kim

BUSCH GROUP

The Busch Group is one of the world's largest manufacturers of vacuum pumps, vacuum systems, blowers, compressors and gas abatement systems. Under its umbrella, the group houses three well-known brands: Busch Vacuum Solutions, Pfeiffer Vacuum and centrotherm clean solutions. Together, they offer solutions to a wide range of industries. A global network of highly competent local teams in 44 countries ensures that expert, tailor-made support is always available near you. Wherever you are. Whatever your business.

