



VACUUM SOLUTIONS

Part of the **BUSCH** GROUP

R5

Oil-lubricated Rotary Vane Vacuum Pumps
KD 0025 A

Instruction Manual



Table of Contents

1	Safety	3
2	Product Description	4
2.1	Operating Principle	5
2.2	Intended Use	5
2.3	Oil Separator Variants	6
2.4	Start Controls.....	6
2.5	Optional Accessories.....	6
2.5.1	Rubber feet.....	6
2.5.2	Extension Cables.....	6
3	Transport and Handling	7
4	Storage.....	8
5	Installation.....	9
5.1	Installation Conditions	9
5.2	Connecting Lines / Pipes	10
5.2.1	Inlet Connection	10
5.2.2	Exhaust Connection	11
5.3	Filling Oil.....	11
6	Electrical Connection	12
6.1	Machine delivered without Control Box or Variable Speed Drive (VSD)	12
6.2	Wiring Diagram Single-Phase Motor	13
6.3	Wiring Diagram Three-Phase Motor.....	14
6.4	Capacitor Installation.....	15
6.5	Motor Variants.....	16
6.6	Extension Cable Variants.....	16
7	Commissioning	18
7.1	Conveying Condensable Vapors.....	19
8	Maintenance	20
8.1	Maintenance Schedule	21
8.2	Oil Level Inspection.....	21
8.3	Oil Change.....	21
8.4	Exhaust Filter Change.....	23
9	Overhaul	24
10	Decommissioning	25
10.1	Dismantling and Disposal	25
11	Spare Parts	26
12	Troubleshooting	27
13	Technical Data	29
14	Oil	30
15	EU Declaration of Conformity	31
16	UK Declaration of Conformity.....	32

1 Safety

Prior to handling the machine, this instruction manual should be read and understood. If anything needs to be clarified, please contact your manufacturer representative.

Read this instruction manual carefully before use and keep for future reference.

This instruction manual remains valid as long as the customer does not change anything on the product.

The machine is intended for industrial use. It must be handled only by technically trained personnel.

Always wear appropriate personal protective equipment in accordance with the local regulations.

The machine has been designed and manufactured in accordance with the state-of-the-art methods. Nevertheless, residual risks may remain, as described in the following chapters and in accordance with the chapter *Intended Use* [→ 5].

This instruction manual highlights potential hazards where appropriate. Safety notes and warning messages are tagged with one of the keywords DANGER, WARNING, CAUTION, NOTICE and NOTE as follows:



DANGER

... indicates an imminent dangerous situation that will result in death or serious injuries if not prevented.



WARNING

... indicates a potentially dangerous situation that could result in death or serious injuries.



CAUTION

... indicates a potentially dangerous situation that could result in minor injuries.



NOTICE


... indicates a potentially dangerous situation that could result in damage to property.



NOTE

... indicates helpful tips and recommendations, as well as information for efficient and trouble-free operation.

2 Product Description



Description			
IN	Inlet connection	OUT	Exhaust connection
CAP	Capacitor (single-phase motor only)	CS	Capacitor support
DA	Directional arrow	EF	Exhaust filter
LE	Lifting eye	NP	Name plate
ODP	Oil drain plug	OFP	Oil fill plug
OSG	Oil sight glass	PS	Power supply

NOTE

Technical term.


In this instruction manual, we consider that the term ‘machine’ refers to the ‘vacuum pump’.

NOTE

Illustrations.

In this instruction manual, the illustrations may differ from the appearance of the machine.

2.1 Operating Principle



The machine works on the rotary vane principle.

The oil seals the gaps, lubricates the vanes and takes away compression heat.

In order to avoid reverse rotation after switching off, the machine is equipped with a non-return valve (NRV).

In order to avoid solids from entering, the machine is equipped with an inlet screen (IS).

Exhaust filters separate the oil from the exhaust gas.

2.2 Intended Use



WARNING

In case of foreseeable misuse outside the intended use of the machine.

Risk of injuries!

Risk of damage to the machine!

Risk of damage to the environment!

- Make sure to follow all instructions described in this manual.

The machine is intended for the suction of air and other dry, non-aggressive, non-toxic, non-ignitable and non-explosive gases.



NOTE

If the machine is started against vacuum.

The oil temperature must be above 25 °C to ensure reliable and safe start-up.

Conveying of other media leads to an increased thermal and/or mechanical load on the machine and is permissible only after a consultation with the manufacturer.

The machine is designed to be integrated into vacuum packaging table-top machines.

The machine is intended for placement in a non-potentially explosive environment.

The machine is designed for indoor installations. For outdoor installations, consult your Busch representative for special precautions.

The machine is capable of maintaining ultimate pressure, see *Technical Data* [→ 29].

Permitted environmental conditions, see *Technical Data* [→ 29].

2.3 Oil Separator Variants



Description			
1	Short oil separator	2	Long oil separator

2.4 Start Controls

The machine comes without start controls. The control of the machine is to be provided in the course of installation.

The machine can be equipped with a soft-starter.

2.5 Optional Accessories

2.5.1 Rubber feet

The rubber feet isolate and reduce the vibration of the machine.

Fix the pump unit to the housing. Use M6-screws for the rubber foot of long oil separator version and M8-screws for the short oil separator version and tighten them.

2.5.2 Extension Cables

See *Extension Cable Variants* [→ 16].

3 Transport and Handling




WARNING

Suspended load.

Risk of severe injury!

- Do not walk, stand, or work under suspended loads.
- To find out the weight of the machine, refer to the chapter *Technical Data* [→ 29] or the name plate (NP).



Description			
1	Use the lifting eye (LE) to lift the machine		

- Check that the machine has not been damaged during transport.
- If the machine is mounted and secured on a transport support (pallet):
- Remove the machine from the transport support before installation.

4 Storage

- Seal hermetically all apertures with the caps provided with the machine, or with adhesive tape if the caps are no longer available.
- Store the machine indoors, in a dry place, away from dust and vibrations and if possible, in original packaging, preferably at temperatures between 0 ... 40 °C.

If the machine is to be stored for more than 3 months:

- Seal hermetically all apertures with the caps provided with the machine, or with adhesive tape if the caps are no longer available.
- Wrap the machine in a corrosion inhibitor film.
- Store the machine indoors, in a dry place, away from dust and vibrations and if possible, in original packaging, preferably at temperatures between 0 ... 40 °C.

5 Installation

5.1 Installation Conditions




NOTICE

Use of the machine outside of the permitted installation conditions.

Risk of premature failure!

Loss of efficiency!

- Make sure that the installation conditions are fully respected.



Description

1	~20 cm	2	~20 cm
3	~20 cm	4	~20 cm

- Make sure that the environment of the machine is not potentially explosive.
- Make sure that the ambient conditions comply with the *Technical Data* [→ 29].
- Make sure that the environmental conditions comply with the protection class of the motor and the electrical elements.
- Make sure that the installation space or location is protected from weather and lightning.
- Make sure that the installation space or location is vented such that sufficient cooling of the machine is provided.
- Make sure that the oil sight glass (OSG) remains easily visible.
- Make sure that enough space remains for maintenance work.
- Make sure that the machine is placed or mounted horizontally, a maximum deviation of 1° in any direction is acceptable.
- Check the oil level, fill up if necessary, see *Filling Oil* [→ 11].
- Make sure that all provided covers, guards, hoods, etc. are mounted.

- Fix the pump unit with M6-screws for the long oil separator version and M8-screws for the short oil separator version to the housing of the table top packing machine.



NOTE

It is possible to use the same fixing screws even if the rubber feet are used to absorb vibration.

- For more information about installation conditions, contact your Busch representative.

5.2 Connecting Lines / Pipes

- Remove all protective covers before installation.
- Make sure that the connection lines cause no stress on the connections of the machine. Therefore, we recommend installing flexible lines at the inlet and exhaust connections.
- Make sure that the diameter of the connecting lines over the entire length is at least as large as the connections of the machine.

In case of long connecting lines:

- Use larger diameters to avoid a loss of efficiency.
- Contact your manufacturer representative for more information.

5.2.1 Inlet Connection



NOTICE

Ingress of foreign objects or liquids.

Risk of damage to the machine!

If the inlet gas contains dust or other foreign solid particles:

- Install a suitable filter (5 micron or less) at the inlet of the machine.



NOTICE

Using the non-return valve as shut off valve.

Risk of oil mist flow back into the vacuum system.

- It is highly recommended not to use the non-return valve as a shut off system.

Connection size(s):

– G ½"

- Make sure that the connection lines cause no stress on the connections of the machine. Therefore, we recommend installing flexible lines at the inlet and exhaust connections.

5.2.2 Exhaust Connection



CAUTION

The exhaust gas contains small quantities of oil.

Risk to health!

If air is discharged into rooms where persons are present:

- Make sure that sufficient ventilation is provided.

Connection size(s):

- Without connection: The exhaust gas is released to the ambient of the machine.
- Make sure that the connection lines cause no stress on the connections of the machine. Therefore, we recommend installing flexible lines at the inlet and exhaust connections.

5.3 Filling Oil



NOTICE


Use of inappropriate oil.

Risk of premature failure!

Loss of efficiency!

- Use only a type of oil previously approved and recommended by the manufacturer.

For oil type and oil capacity see *Technical Data* [→ 29] and *Oil* [→ 30] chapters.



Description

1	1x o-ring, article no.: 0486 000 590	2	Tightening torque: 12 Nm
---	--------------------------------------	---	--------------------------

6 Electrical Connection



DANGER

Live wires.

Risk of electrical shock!

- Electrical installation work must only be executed by qualified personnel.

INSTALLATION(S) CURRENT PROTECTION:



DANGER

Missing current protection.

Risk of electrical shock!

- Provide current protection in accordance with EN 60204-1 on your installation(s).
- The electrical installation must comply with the applicable national and international standards.



NOTICE

Electromagnetic compatibility.

- Make sure that the motor of the machine will not be affected by electric or electromagnetic disturbance from the mains. If necessary, contact your Busch representative for more information.
- Make sure that the EMC of the machine is compliant with the requirements of your supply network system, if necessary, provide further interference suppression (EMC of the machine, see *EU Declaration of Conformity* [→ 31] or *UK Declaration of Conformity* [→ 32]).

6.1 Machine delivered without Control Box or Variable Speed Drive (VSD)



DANGER

Live wires.

Risk of electrical shock!

- Electrical installation work must only be executed by qualified personnel.
- Make sure that the power supply for the motor is compatible with the data on the name plate of the motor.
- If the machine is equipped with a power connector, install a residual current protective device to protect persons in case of a defective insulation.
 - Busch recommends installing a type B residual protective device suitable for the electrical installation.
- Provide a lockable disconnect switch or an emergency stop switch on the power line so that the machine is completely secured in case of an emergency situation.

- Provide a lockable disconnect switch on the power line so that the machine is completely secured during maintenance tasks.
- Provide an overload protection according to EN 60204-1 for the motor.
 - Busch recommends installing a D-curve circuit breaker.
- Install the capacitor (single-phase motor only) and connect it to the capacitor connection (CC), see *Capacitor Installation* [→ 15].
- Electrically connect the motor.


6.2 Wiring Diagram Single-Phase Motor



NOTICE

Machines with single-phase motors equipped with a starting capacitor.

Higher noise level during the start-up phase and possible additional mechanical and electrical vibrations, due to starting current and torque increased by the starting capacitor.



- Type: Universal MATE-N-LOK cap housing, 5-Circuits (art. no. 350810 – 1)
- Contact type: Sockets (art. no. 926882 – 1)
- Contact assignment: 1 = L1; 2 = PE; 3 = N; 4-5 = Capacitor

Motor Specifications

Nominal motor rating	0.75 / 0.9 kW
Frame size and flange	80 / B34
Protection class	Min. IP 20
Insulation class	F
Duty type	S1 duty
Thermal motor protection	No
Connector type	AMP plug




NOTE

For information on motor and extension cable variants.

- See *Motor Variants* [→ 16].
- See *Extension Cable Variants* [→ 16].

6.3 Wiring Diagram Three-Phase Motor



- Type: Universal MATE-N-LOK cap housing, 4-Circuits (art. no. 350780 – 1)
- Contact type: Sockets (art. no. 926882 – 1)
- Contact assignment: 1 = L1; 2 = PE; 3 = L2; 4 = L3

! NOTICE

Incorrect direction of rotation.

Risk of damage to the machine!

- Operation in the wrong direction of rotation can destroy the machine in a short time! Prior to start-up, ensure that the machine is operated in the right direction.

i NOTE

For information on motor and extension cable variants.

- See *Motor Variants* [→ 16].
- See *Extension Cable Variants* [→ 16].

6.4 Capacitor Installation


The machine needs a suitable capacitor (CAP) to operate, see *Motor Variants* [→ 16].

Depending on the order placed, the scope of delivery contains one of the following delivery options.

Delivery Option 1

The capacitor (CAP) is delivered loosely

- Install the capacitor (CAP) on the capacitor's support (CS) of the motor and connect it with cable to power connection, as shown in the illustration.



- For thermal reasons, the capacitor (CAP) can be mounted at a different location. Maximum distance of 230 mm (cable length) from the power connection.

Delivery Option 2

The capacitor (CAP) is installed and connected on the capacitor's support (CS)

Delivery Option 3

No capacitor (CAP)

- Depending on the motor, install a suitable capacitor (CAP), see *Motor Variants* [→ 16].
- Install the capacitor (CAP) on the capacitor's support (CS) of the motor and connect it with cable to power connection, as shown in the illustration.



NOTE

For information on motor and extension cable variants.

- See *Motor Variants* [→ 16].
- See *Extension Cable Variants* [→ 16].


6.5 Motor Variants

Variant	Voltage (V)	Frequency (Hz)	Speed (min ⁻¹)	Capacitor Capacitance	Capacitor Voltage (V)
EU Single-phase	220 – 240	50 / 60	3000 / 3600	60 µF	400
US Single-phase	110 / 110 – 120	50 / 60	3000 / 3600	100 µF	250
JP Three-phase	200 / 346	50	3000 UpM	n/a	n/a
	200 / 380	60	3600 UpM	n/a	n/a
	200 / 346	60	3600 UpM	n/a	n/a


6.6 Extension Cable Variants

Single-Phase Motor

- Type: AMP plug to wire end ferrules
- Article no. 0671 234 891, length 1000 mm




- Type: AMP plug to wire end ferrules (cURus)
- Article no. 0671 239 005, length 1000 mm




Three-Phase Motor

- Type: AMP plug to wire end ferrules
- Article no. 0671 239 004, length 1000 mm




EU Motor (KI) and US Motor (KK)

- Type: AMP plug to AMP plug
- Article no. 2000 060 493, length 400 mm



- Type: AMP plug to AMP plug, cURus
- Article no. 2000 060 557, length 400 mm



7 Commissioning



CAUTION

In operation, the surface of the machine may reach temperatures over 70°C.

Risk of burns!

- Avoid contact with the machine during and directly after operation.



CAUTION



Noise of running machine.

Risk of damage to hearing!

If people are present in the vicinity of a machine that is not insulated from noise for extended periods of time:

- Make sure to wear hearing protection.



NOTICE

The machine is normally shipped without oil.

Operation without oil will ruin the machine in short time!

- Prior to commissioning, the machine must be filled with oil, see *Filling Oil* [→ 11].

- Make sure that the *Installation Conditions* [→ 9] are met.
- Start the machine.
- Make sure that the operating conditions comply with the *Technical Data* [→ 29].
- After a few minutes of operation, perform an *Oil Level Inspection* [→ 21].

As soon as the machine is used under normal operating conditions:

- Measure the motor current and record it as reference for future maintenance and troubleshooting work.

7.1 Conveying Condensable Vapors



CAUTION

Venting the machine.

The discharged gases and/or liquids may reach temperatures above 70°C!

Risk of burns!

- Avoid direct contact with the flow of gases and/or liquids.



CAUTION



Noise of running machine.

Risk of damage to hearing!

If people are present in the vicinity of a machine that is not insulated from noise for extended periods of time:

- Make sure to wear hearing protection.

Water vapor within the gas flow is tolerated within certain limits. The conveyance of other vapors shall be agreed upon with the manufacturer.

If condensable vapors are to be conveyed:

Before process:

- Warm up the machine for approximately half an hour.

After process:

- Run the machine for about another half hour.

8 Maintenance



DANGER

Live wires.

Risk of electrical shock!

- Electrical installation work must only be executed by qualified personnel.



WARNING



The machine is contaminated with hazardous material.

Risk of poisoning!

Risk of infection!

If the machine is contaminated with hazardous material:

- Wear appropriate personal protective equipment.



CAUTION

Hot surface.

Risk of burns!

- Before doing anything that requires touching the machine, let it cool down first.



CAUTION

Hot liquids.

Risk of burns!

- Before draining liquids, let the machine cool down first.



CAUTION

Failing to properly maintain the machine.

Risk of injuries!

Risk of premature failure and loss of efficiency!

- Maintenance work must only be executed by qualified personnel.
- Respect the maintenance intervals or ask your Busch representative for service.



NOTICE

Using inappropriate cleaners.

Risk of removing safety stickers and protective paint!

- Do not use incompatible solvents to clean the machine.

- Stop the machine and lock it to prevent accidental start-up.
- Vent the connected lines to atmospheric pressure.

If necessary:

- Disconnect all connections.

8.1 Maintenance Schedule


The maintenance intervals depend very much on the individual operating conditions. The intervals given below are considered as starting values which should be individually shortened or extended as appropriate.

Particularly harsh applications or heavy-duty operation, such as high dust loads in the environment or in the process gas, other contamination or ingress of process material, can make it necessary to shorten the maintenance intervals significantly.

Interval	Maintenance work
Daily	• Check the oil level, see <i>Oil Level Inspection</i> [→ 21].
Weekly	• Check the machine for oil leaks. In case of leaks have the machine repaired (contact Busch).
Every 2000 hours or every 6 months	• Change the oil and the exhaust filters (EF).
Every 5 years	• Have a major overhaul on the machine (contact the manufacturer).

8.2 Oil Level Inspection

- Stop the machine.
- Wait 1 minute.
- Check the oil level.



- Fill up if necessary, see *Filling Oil* [→ 11].

8.3 Oil Change




NOTICE

Use of inappropriate oil.

Risk of premature failure!


Loss of efficiency!

- Use only a type of oil previously approved and recommended by the manufacturer.




Description			
1	1x o-ring, article no.: 0486 000 505	2	Tightening torque: 12 Nm

For oil type and oil capacity see *Technical Data* [→ 29] and *Oil* [→ 30] chapters.



Description			
1	1x o-ring, article no.: 0486 000 590	2	Tightening torque: 12 Nm

8.4 Exhaust Filter Change



Description

1	Tightening torque: 4 Nm		
---	-------------------------	--	--

9 Overhaul



WARNING



The machine is contaminated with hazardous material.

Risk of poisoning!

Risk of infection!

If the machine is contaminated with hazardous material:

- Wear appropriate personal protective equipment.



NOTICE

Incorrect assembly.

Risk of premature failure!

Loss of efficiency!

- Any disassembly of the machine beyond that described in this manual must be carried out by technicians approved by Busch.

If the machine has conveyed gas contaminated with foreign materials which are hazardous to health:

- Decontaminate the machine as much as possible and state the contamination status in a 'Declaration of Contamination'.

The manufacturer will only accept machine accompanied by a signed, fully completed and legally binding "declaration of contamination", downloadable from the following link: buschvacuum.com/declaration-of-contamination.

10 Decommissioning



DANGER

Live wires.

Risk of electrical shock!

- Electrical installation work must only be executed by qualified personnel.



CAUTION

Hot surface.

Risk of burns!

- Before doing anything that requires touching the machine, let it cool down first.



CAUTION

Hot liquids.

Risk of burns!

- Before draining liquids, let the machine cool down first.
- Stop the machine and lock it to prevent accidental start-up.
- Disconnect the power supply.
- Vent the connected lines to atmospheric pressure.
- Disconnect all connections.

If the machine is to be stored:

- See *Storage* [→ 8].

10.1 Dismantling and Disposal

- Drain and collect the oil.
- Make sure that no oil drips onto the floor.
- Remove the exhaust filters.
- Separate special waste from the machine.
- Dispose of special waste in compliance with applicable regulations.
- Dispose of the machine as scrap metal.

11 Spare Parts



NOTICE

Use of non-Busch genuine spare parts.

Risk of premature failure!

Loss of efficiency!

- Use only Busch genuine spare parts, consumables and supplies to ensure correct operation of the machine and to validate the warranty.

Spare part	Description	Article number
Service kit	Includes all parts to perform maintenance work	0990 241 154

If other parts are required:

- Contact your Busch representative.

12 Troubleshooting



DANGER

Live wires.

Risk of electrical shock!

- Electrical installation work must only be executed by qualified personnel.



CAUTION

Hot surface.

Risk of burns!

- Before doing anything that requires touching the machine, let it cool down first.




CAUTION

Hot liquids.

Risk of burns!

- Before draining liquids, let the machine cool down first.

Illustration showing parts that may be involved during troubleshooting:



Description			
EF	Exhaust filter	IS	Inlet screen
M1 x4	Tightening torque: 10Nm	M2 x4	Tightening torque: 4Nm

Problem	Possible Cause	Remedy
The machine does not start.	The motor is not supplied with the correct voltage.	• Check the power supply. • Have the machine repaired (contact Busch Service).
	The capacitor is defective. (Single phase motor only)	• Check the capacitor as well as the connection.
	The machine heated up, disconnection by bimetallic element.	• Have the machine cool down.
The machine does not reach the usual pressure at the inlet connection.	Oil level too low.	• Top up oil.
	The inlet screen (IS) is partially clogged.	• Clean the inlet screen (IS).
	Internal parts are worn or damaged.	• Repair the machine (contact Busch).
The machine runs very noisily.	Stuck vanes.	• Repair the machine (contact Busch).
	Defective bearings.	• Repair the machine (contact Busch).
The machine runs too hot.	Insufficient cooling.	• Remove dust and dirt from the machine.
	Ambient temperature too high.	• Observe the permitted ambient temperature.
	Oil level too low.	• Top up oil.
	The exhaust filters (EF) are partially clogged.	• Replace the exhaust filters (EF).
The machine fumes or expels oil droplets through the exhaust gases.	The exhaust filters (EF) are partially clogged.	• Replace the exhaust filters (EF).
	An exhaust filter (EF) with o-ring is not fitted properly.	• Ensure the correct position of the exhaust filters (EF) and the o-rings.
The oil is black.	Oil change intervals are too long.	• Flush the machine (contact Busch).
	The machine runs too hot.	• See problem "The machine runs too hot".
The oil is emulsified.	The machine sucked in liquids or significant amounts of vapor.	• Flush the machine (contact Busch).

For resolution of problems not listed in the troubleshooting table, contact your Busch representative.

13 Technical Data

KD 0025 A		
Nominal pumping speed (50 / 60 Hz)	m ³ /h	22 / 25
Ultimate pressure (50 / 60 Hz)	hPa (mbar) abs.	2.0 / 2.0
Nominal motor rating (50 / 60 Hz)	kW	0.75 / 0.9
Nominal motor speed (50 / 60 Hz)	min ⁻¹	3000 / 3600
Sound pressure level (ISO 2151) (50 / 60 Hz) KD 0025 A short separator	dB(A)	62 / 67
Sound pressure level (ISO 2151) (50 / 60 Hz) KD 0025 A long separator	dB(A)	64 / 68
Ambient temperature	°C	5 ... 40 *
Inlet gas temperature	°C	5 ... 40 *
Ambient pressure		Atmospheric pressure
Oil capacity KD 0025 A short separator	l	0.3
Oil capacity KD 0025 A long separator	l	0.45
Weight approx.	kg	21 **

* In case of higher or lower temperatures, please consult your Busch representative.

** The weight can vary depending on the order.

14 Oil

Name	ISO-VG	Oil type	0.1 L packing	0.5 L packing	1 L packing	5 L packing
VSA 032	32	Synthetic	-	-	0831 163 958	0831 163 961
VSB 032	32	Synthetic	-	-	0831 168 343	0831 168 344

In case of unfavorable ambient temperature, other oil viscosities can be used.

- For more information, contact your Busch representative.

To find out which oil needs to be filled into the machine, refer to the name plate (NP).

Oil suitability

- **Oil VSA 032:** Suitable for food applications (H1)
 - With additives against corrosion
 - Light cycle operation (long downtime)
 - Operating oil temperature <100°C
 - Compliant with kosher and halal standards.
- **Oil VSB 032:** Suitable for food applications (H1)
 - Continuous operation
 - Compliant with kosher and halal standards.

15 EU Declaration of Conformity

This Declaration of Conformity and the CE-markings affixed to the name plate are valid for the machine within the Busch scope of delivery. This Declaration of Conformity is issued under the sole responsibility of the manufacturer.

When this machine is integrated into a superordinate machinery, the manufacturer of the superordinate machinery (this can be the operating company, too) must conduct the conformity assessment process for the superordinate machine or plant, issue the Declaration of Conformity for it and affix the CE-marking.

The manufacturer

Busch Výroba CZ s.r.o.
Svárovská 620
CZ 460 01, Liberec 11

declares that the machine: vacuum pump R5 KD 0025 A

fulfill(s) all the relevant provisions from EU directives:

- 'Machinery Directive' 2006/42/EC, if the serial number is less than or equal to CZM126999999
- 'Machinery Regulation' (EU) 2023/1230, if the serial number is greater than or equal to CZM127000000
- 'Electromagnetic Compatibility' (EMC) 2014/30/EU
- 'RoHS' 2011/65/EU Restriction of the use of certain hazardous substances in electrical and electronic equipment (incl. all related applicable amendments)

and comply(-ies) with the following harmonized standards that have been used to fulfill those provisions:

Standard	Title of the Standard
EN ISO 12100 : 2010	Safety of machinery - Basic concepts, general principles of design
EN 1012-2 : 1996 + A1 : 2009	Vacuum pumps - Safety requirements - Part 2
EN 60204-1 : 2018	Safety of machinery - Electrical equipment of machines - Part 1: General requirements
EN ISO 13857 : 2019	Safety of machinery - Safety distances to prevent hazard zones being reached by the upper and lower limbs
EN ISO 2151 : 2008	Acoustics - Noise test code for compressors and vacuum pumps - Engineering method (grade 2)
EN IEC 61000-6-2 : 2019	Electromagnetic compatibility (EMC) - Generic standards. Immunity for industrial environments
EN IEC 61000-6-4 : 2019	Electromagnetic compatibility (EMC) - Generic standards. Emission standard for industrial environments

Legal person authorized to compile the technical file and authorized representative in the EU (if the manufacturer is not located in the EU):

Busch Dienste GmbH
Schauinslandstr. 1
DE-79689 Maulburg

Liberec, 2025.04.07



Michael Dostalek, General Manager
Busch Výroba CZ s.r.o.

16 UK Declaration of Conformity

This Declaration of Conformity and the UKCA-markings affixed to the name plate are valid for the machine within the Busch scope of delivery. This Declaration of Conformity is issued under the sole responsibility of the manufacturer.

When this machine is integrated into a superordinate machinery, the manufacturer of the superordinate machinery (this can be the operating company, too) must conduct the conformity assessment process for the superordinate machine or plant, issue the Declaration of Conformity for it and affix the UKCA-marking.

The manufacturer

Busch Výroba CZ s.r.o.
Svárovská 620
CZ 460 01, Liberec 11

declares that the machine: vacuum pump R5 KD 0025 A

fulfill(s) all the relevant provisions from UK legislations:

- Supply of Machinery (Safety) Regulations 2008
- Electromagnetic Compatibility Regulations 2016
- Restriction of the use of certain hazardous substances in Electrical and Electronic Equipment Regulations 2012

and comply(-ies) with the following designated standards that have been used to fulfill those provisions:

Standard	Title of the Standard
EN ISO 12100 : 2010	Safety of machinery - Basic concepts, general principles of design
EN 1012-2 : 1996 + A1 : 2009	Vacuum pumps - Safety requirements - Part 2
EN 60204-1 : 2018	Safety of machinery - Electrical equipment of machines - Part 1: General requirements
EN ISO 13857 : 2019	Safety of machinery - Safety distances to prevent hazard zones being reached by the upper and lower limbs
EN ISO 2151 : 2008	Acoustics - Noise test code for compressors and vacuum pumps - Engineering method (grade 2)
EN IEC 61000-6-2 : 2019	Electromagnetic compatibility (EMC) - Generic standards. Immunity for industrial environments
EN IEC 61000-6-4 : 2019	Electromagnetic compatibility (EMC) - Generic standards. Emission standard for industrial environments

Legal person authorized to compile the technical file and importer in the UK (if the manufacturer is not located in the UK):

Busch (UK) Ltd
30 Hortonwood
Telford – UK

Liberec, 2025.04.07



Michael Dostalek, General Manager
Busch Výroba CZ s.r.o.

Notes

Grid of dots for notes.

A large rectangular area filled with a uniform grid of small, light gray dots, intended for handwritten notes.

A large grid of dots for taking notes, consisting of 20 columns and 30 rows of small, light gray dots.

BUSCH GROUP

The Busch Group is one of the world's largest manufacturers of vacuum pumps, vacuum systems, blowers, compressors and gas abatement systems. Under its umbrella, the group houses two well-known brands: Busch Vacuum Solutions and Pfeiffer Vacuum+Fab Solutions. Together, they offer solutions to a wide range of industries. A global network of highly competent local teams in 44 countries ensures that expert, tailor-made support is always available near you. Wherever you are. Whatever your business.



● Busch Group companies

▲ Busch Group production sites

● Busch Group service centers

■ Busch Group local representatives

www.buschvacuum.com

www.pfeiffer-vacuum.com